

Copley Motion Objects (CMO) Programmer's Guide



P/N 95-00290-000

Revision 4
June 2008

TABLE OF CONTENTS

Product Warnings	ii
About This Manual	iii
1: Introduction	1
1.1: Windows-Based Control of Copley Amplifiers	2
1.2: Basic System Requirements	3
2: Installation	5
2.1: Installation Overview	6
2.2: Installation Procedures	6
3: Fundamental Concepts and Procedures	7
3.1: Before Running a Copley Motion Objects Program	8
3.2: CAN Network	9
3.3: Adding a Reference to a Program	10
3.4: Object Initialization Sequence	12
3.5: Objects Contained by AmpObj	12
3.6: Node Guarding	14
3.7: Error Handling	15
3.8: Units	15
3.9: Stepnet Amplifiers	16
A: CANopen Object	17
A.1: CANopen	17
B: Amplifier and Related Objects	19
B.1: AmpSettingsObj	20
B.2: Amplifier Initialization	21
B.3: Amplifier Information	21
B.4: Motor/Feedback Information	24
B.5: Save/Restore Amplifier Data	27
B.6: Node Guarding	27
B.7: Current Loop	27
B.8: Velocity Loop	29
B.9: Position Loop	30
B.10: Tracking Windows	31
B.11: Status, Events, and Faults	31
B.12: Amplifier Digital Inputs/Outputs	35
B.13: Amplifier Enable/Disable	39
B.14: Homing	40
B.15: Quick Stop	43
B.16: Point-to-Point Moves	44
B.17: Amplifier Events	45
B.18: Amplifier Trace Methods and Properties	46
B.19: Other Methods and Properties	49
C: The Linkage Object	53
C.1: Linkage Object (LinkageObj)	53
D: The Event Object	57
D.1: Event Object	58
E: The I/O Object	59
E.1: I/O Modules	60
F: CopleyMotionLibrary Object	65
F.1: CopleyMotionLibraryObj	66
G: Masking	67
G.1: Masking	67
H: Object Revision History	69
H.1: Object Revision History	69

PRODUCT WARNINGS

**WARNING**

Use caution in designing and programming machines that affect the safety of operators.

The examples in this book are for demonstration purposes only, providing guidelines for programming. The programmer is responsible for creating program code that operates safely for the amplifiers and motors in any given machine.

Failure to adhere to this warning can cause equipment damage, injury, or death.

**WARNING**

Do not use Copley Motion Objects to implement an Emergency Stop

An Emergency Stop must be hardwired directly to the amplifier. Do not depend on the Copley Motion Objects software to provide for a timely emergency stop. Due to the non-deterministic nature of Microsoft Windows, the software cannot guarantee a timely emergency stop operation.

Failure to adhere to this warning can cause equipment damage, injury, or death.

ABOUT THIS MANUAL

Overview and Scope

This manual describes the installation and use of Copley Motion Objects.

Related Documentation

Readers of this book should also read information on CAN and CANopen at the "CAN in Automation" website at <http://www.can-cia.de/>.

More information on the Copley Controls implementation of CANopen objects can be found in Copley Controls' *CANopen Programmer's Manual*:

<http://www.copleycontrols.com/Motion/pdf/CANopenProgrammersManual.pdf>

For information on connecting an amplifier to the CANopen Network, see Copley Controls *CANopen Network CANBus Cabling Guide* at:

<http://www.copleycontrols.com/Motion/pdf/CAN-Bus.pdf>.

Information on other Copley Controls Software can be found at:

<http://www.copleycontrols.com/Motion/Products/Software/index.html>.

For more information on Microsoft's COM architecture, please refer to:

<http://www.microsoft.com/com/>.

Comments

Copley Controls Corp. welcomes your comments on this manual.

See <http://www.copleycontrols.com> for contact information.

Copyrights

No part of this document may be reproduced in any form or by any means, electronic or mechanical, including photocopying, without express written permission of Copley Controls Corp.

CME 2 and CMO are registered trademarks of Copley Controls Corporation.

Windows NT, 2000, and XP, Visual Basic, and .NET are trademarks or registered trademarks of the Microsoft Corporation.

LabVIEW is a registered trademark of National Instruments.

Document Validity

We reserve the right to modify our products. The information in this document is subject to change without notice and does not represent a commitment by Copley Controls Corp.

Copley Controls Corp. assumes no responsibility for any errors that may appear in this document.

Revision History

Release	Date	DECO #	Comments
1.0	September 2003		Initial publication.
1.1	March 2004		Reorganized.
3	December 2006	14845	New features.
4	June 2008	17137	Updated Web page references.

CHAPTER

1: INTRODUCTION

This chapter provides an overview of Copley Motion Objects.

Contents include:

1.1: Windows-Based Control of Copley Amplifiers	2
1.1.1: Simplified Access to CANopen Functions.....	2
1.1.2: Architectural Overview	2
1.2: Basic System Requirements	3
1.2.1: Computer and Operating System	3
1.2.2: Software	3
1.2.3: CAN Interface Card.....	3
1.2.4: Amplifier Firmware	3


1.1: Windows-Based Control of Copley Amplifiers

1.1.1: Simplified Access to CANopen Functions

The Copley Motion Objects simplify creation of Windows-based software for the control of Copley Controls amplifiers over a CANopen network. They give programmers direct access to an amplifier's CANopen functions without having to learn the complexities of CANopen objects. Copley Motion Objects were built using the Microsoft Component Object Model (COM) architecture, and are fully automation compliant. This means that any Microsoft COM-compliant software can access the Copley Motion Objects.

1.1.2: Architectural Overview

The following diagram illustrates the Copley Motion Objects/Microsoft COM model.



1.2: Basic System Requirements

1.2.1: Computer and Operating System

Minimum hardware requirements:

- **CPU:** Minimum 400 MHz
- **RAM:** Minimum 128 MB

Operating Systems Supported: NT, 2000, XP.

1.2.2: Software

Copley Controls CME 2 software (latest released version) for tuning and configuration of the amplifier.

The Copley Motion Objects were built using the Microsoft COM architecture and are fully automation compliant. Any COM-compliant software can access them. This includes, but is not limited to, VB 6.0, VB .NET, Visual C++, and LabVIEW.

1.2.3: CAN Interface Card

The PC on which Copley Motion Objects is installed needs a CAN interface card for communication with the CAN network. CMO currently supports Copley, Kvaser, IXXAT, National Instruments, and Vector. The current list of supported CAN interface cards can be obtained from the Copley Controls website (<http://www.copleycontrols.com>).

NOTE: Only the drivers from Vector are supported for the Vector card.

1.2.4: Amplifier Firmware

Use of Copley Motion Objects requires the latest version of Copley Controls amplifier firmware. The latest version can be downloaded at:

<http://www.copleycontrols.com/Motion/Downloads/firmware.html>

CHAPTER

2: INSTALLATION

This chapter describes the installation of Copley Motion Objects on a PC.

Chapter contents include:

2.1: Installation Overview	6
2.2: Installation Procedures	6
2.2.1: Downloading Software from Web (Optional).....	6
2.2.2: Installing Copley Motion Objects Software	6

2.1: Installation Overview

The procedures described in this chapter copy the Copley Motion Objects, examples, and documentation to the target PC. They also register the Copley Motion Object Dynamic Link Library (.dll) file on the host PC. Once the Copley Motion Objects are in the Windows Registry, any program that uses Microsoft COM can access them.

In addition, shortcuts to the examples and documentation are placed in the Start→Programs→Copley Motion→CMO menu path.

2.2: Installation Procedures

2.2.1: Downloading Software from Web (Optional)

- 2.2.1.1 Choose or create a folder where you will download the software installation file.
- 2.2.1.2 In an internet browser, navigate to
<http://www.copleycontrols.com/Motion/Downloads/index.html>.
- 2.2.1.3 Under *Software*, click on **CMO**.
- 2.2.1.4 When prompted, save the file to the folder chosen or created in Step 2.2.1.1.
The folder should now contain a file named *CMO.zip*.
- 2.2.1.5 Extract the contents of the zip file to the same location.
The folder should now contain the files *CMO.zip*, *CMO License.txt*, *Setup.exe*, and *ReleaseNotes.txt*.
- 2.2.1.6 If desired, delete *CMO.zip* to save disk space.

2.2.2: Installing Copley Motion Objects Software

- 2.2.2.1 If installing from a Copley Controls CMO CD, insert the CD.
Normally, inserting the CD causes the installation script to launch, and a Copley Motion Objects Installation screen appears. If so, skip to Step 2.2.2.3.
- 2.2.2.2 If the software installation file was downloaded from the Copley Controls website, navigate to the folder chosen or created in Step 2.2.1.1, and then double-click on **Setup.exe**
OR
if you inserted the CD and the Copley Motion Objects *Installation* screen did not appear, navigate to the root directory of the installation CD and then double-click on **Setup.exe**.
- 2.2.2.3 Respond to the prompts on the Copley Motion Objects *Installation* screens to complete the installation. We recommend accepting all default installation values.

CHAPTER

3: FUNDAMENTAL CONCEPTS AND PROCEDURES

Before exploring any of the Copley Motion Objects sample programs or developing a new program, the programmer should be familiar with the contents of this chapter.

Contents include:

3.1: Before Running a Copley Motion Objects Program	8
3.2: CAN Network.....	9
3.2.1: Addressing and Bit Rate	9
3.2.2: CAN Communication and Connection Errors	9
3.3: Adding a Reference to a Program.....	10
3.3.1: Adding a Reference to a Program in VB.....	10
3.3.2: Adding a Reference to a Program in LabVIEW:	11
3.4: Object Initialization Sequence.....	12
3.4.1: CAN Network, and Amplifier Objects	12
3.5: Objects Contained by AmpObj.....	12
3.5.1: Overview	12
3.5.2: Creating and Initializing Objects Contained by AmpObj.....	13
3.5.3: Modifying an AmpObj Object	14
3.6: Node Guarding	14
3.6.1: Node Guarding Overview.....	14
3.6.2: Possibility of False Node Guarding Conditions.....	14
3.7: Error Handling	15
3.8: Units	15
3.8.1: Default Amplifier Units.....	15
3.8.2: User-Defined Units	15
3.9: Stepmotor Amplifiers	16
3.9.1: Stepper and Servo Modes	16
3.9.2: Open Loop Stepper Mode Actual Position and Velocity	16
3.9.3: Stepper Mode with Encoder Actual Position and Velocity	16

3.1: Before Running a Copley Motion Objects Program

The following general steps must be completed before running any Copley Motion Objects program, including the demonstration programs described in this manual:

- 3.1.1.1 Review the [Product Warnings](#) at the beginning of this manual (p. ii).
- 3.1.1.2 Install Copley Motion Objects as described in [Installation](#) (p. 5).
- 3.1.1.3 Install the CAN interface card's driver and hardware. See the CAN card manufacturer's documentation for more details.
- 3.1.1.4 Connect the amplifier, motor, and CAN network.
- 3.1.1.5 Set up and tune the motor and amplifier using Copley Controls CME 2 software. Be sure to set the CAN address and bit rate as described in [CAN Network](#) (p. 9).

3.2: CAN Network

3.2.1: Addressing and Bit Rate

Use Copley Controls CME 2 software to set up the amplifier's CAN address and bit rate.

Setting the CAN address to 0 on an amplifier disables the CAN operation for that amplifier.

In accordance with the CAN DS-102 V2.0 Copley supports bit rates of 1,000, 800, 500, 250, 125, 50, and 20 kb/s.

For more information on changing the CAN address and bit rate settings, see the *CME 2 User Guide*. Manuals are available for download under the *Documents* heading at <http://www.copleycontrols.com/motion/downloads>.

3.2.2: CAN Communication and Connection Errors

Possible CAN communication and connection errors include:

- The CAN address is incorrect
- The bit rate is incorrect
- The wrong CAN channel is connected on a multiple-channel CAN card.
- The CAN bus is improperly terminated.
- CAN bus is wired improperly or disconnected.


If any of these errors occurs, the Copley Motion Object typically responds with the error "SDO Timeout," indicating that there was an attempt to transmit a CANopen SDO information packet, but the packet reception was not confirmed.

3.3: Adding a Reference to a Program

For a program to use the Copley Motion Objects, a reference must first be added. Below are examples of adding a reference to the Copley Motion Objects in various environments.

3.3.1: Adding a Reference to a Program in VB


- 3.3.1.1 In the project workspace menu, choose the add reference command. For instance, in .NET 2005: **Project→Add Reference** to open the *Add Reference* window, then select the COM tab.




- 3.3.1.2 Scroll to highlight the entry for **CMO Type Library**.
- 3.3.1.3 Click **OK**.

3.3.2: Adding a Reference to a Program in LabVIEW:


- 3.3.2.1 From the Refnum controls, choose Automation Refnum.



- 3.3.2.2 Place the Automation Refnum on the Front Panel.



- 3.3.2.3 Right-click on the Automation Refnum block and choose **Select ActiveX Class**. Then browse to the CMO object in the Type Library list. Check **Show Creatable Objects Only** and then select the desired CMO object.



3.4: Object Initialization Sequence

3.4.1: CAN Network, and Amplifier Objects

Every Copley Motion Objects application requires the creation and initialization of at least two basic objects: one to represent the network, and one to represent each amplifier. These objects should always be initialized in the following order:

1. CANopen network object: CANOpenObj. See the CANOpenObj method [Initialize \(p. 17\)](#).
2. Amplifier objects: AmpObj. See the AmpObj method [Initialize \(p. 21\)](#).

Failure to follow this sequence will result in an error.

3.5: Objects Contained by AmpObj

3.5.1: Overview

In addition to numerous methods and properties, the amplifier object is made up of several other objects. These are:

Object	Description
AmpInfoObj	Read-only amplifier characteristics.
MotorInfoObj	A legacy version of MotorInfoObj2.
MotorInfoObj2	All of the motor and feedback parameters.
CurrentLoopSettings	Parameters used for tuning the current loop.
VelocityLoopSettings	Parameters used to tune the velocity loop.
PositionLoopSettings	A legacy version of PositionLoopSettings2.
PositionLoopSettings2	Parameters used to tune the position loop.
HomeSettings	Used configure a homing routine.
ProfileSettings	Used to configure a point-to-point move.
TrackingWindows	Used to configure the position and velocity error windows.

Each of these objects has a set of related methods and properties.


3.5.2: Creating and Initializing Objects Contained by AmpObj

The following examples use the ProfileSettings object to demonstrate the basic methods for using any of the objects contained in the AmpObj.


The AmpObj must first be Initialized before accessing the objects as properties.
(See [Initialize](#) [p. 21].)

There are two ways to create an instance of the ProfileSettings object:

- 3.5.2.1 **Get the instance from the AmpObj.** This is the preferred method, because it sets all of the properties of the ProfileSettings object equal to the values programmed in the amplifier. Platform-specific instructions shown below.


Platform	Command
VB 6.0	Set profileSettings = ampObj.profileSettings
VB .NET	profileSettings = ampObj.ProfileSettings
LabVIEW	

- 3.5.2.2 **Create a new instance.** This sets *default* values for all of the properties. Platform-specific instructions shown below.

Platform	Command
VB 6.0	Set profileSettings = New CMLCOMLib.profileSettings
VB .NET	profileSettings = New CMLCOMLib.ProfileSettings()
LabVIEW	

3.5.3: Modifying an AmpObj Object

Once an instance of the ProfileSettings object has been created as described in [Creating and Initializing Objects Contained by AmpObj](#) (p. 13), any of the properties can be changed and written back to the amplifier. See the platform-specific instructions below.

Platform	Command
VB 6.0	<pre>'Change a property profileSettings.ProfileType = CML_PROFILE_TYPE.PROFILE_VELOCITY 'Write the profile settings to the amplifier ampObj.profileSettings = profileSettings</pre>
VB .NET	<pre>'Change a property profileSettings.ProfileType = CMLCOMLib.CML_PROFILE_TYPE.PROFILE_VELOCITY 'Write the profile settings to the amplifier ampObj.ProfileSettings = profileSettings</pre>
LabVIEW	

3.6: Node Guarding

3.6.1: Node Guarding Overview

Node guarding is a CANopen device-monitoring feature. The network manager configures the amplifier to expect node-guarding messages at some interval. The network manager then sends a message to the amplifier at that frequency, and the amplifier responds with a node-guarding message. This allows both the network manager and the amplifier to identify a network failure if the guarding messages stop. CMO can turn node guarding on or off, and change the interval. If the amplifier detects that the guarding messages stop, it will abort a move in progress and set the [AMPEVENT_NODEGUARD](#) bit active in the [Amplifier Event Register](#) (p. 33). If node guarding is turned on, we recommend monitoring amplifier events for the node guard event. This can be done through the EventObj (see [D: The Event Object](#) [p. 57]) or through a timer, which periodically reads the event mask. See [Node Guarding](#) (p. 27).

3.6.2: Possibility of False Node Guarding Conditions

In a Windows environment, various factors can delay node-guarding messages, resulting in “false” node guarding conditions. These factors include the non-deterministic nature of Windows operating systems and the performance effects of other processes running on the PC. Thus, by default, node guarding is disabled in Copley Motion Objects. If node guarding is required, do not enable node guarding without first testing the performance characteristics and usage load of the PC being used, and adjusting the node guarding parameters accordingly using the [AmpSettingsObj Methods and Properties](#) (p. 20).

3.7: Error Handling

Copley Motion Objects test for error conditions. If an error is present, Copley Motion Objects reports the error in the form of COM-compatible error objects. The error object includes a text description, error number, and the source of the error. For better error handling, each program should include error-handling procedures to guarantee that unexpected motion does not occur.

3.8: Units

3.8.1: Default Amplifier Units

The default Copley Motion Objects units are encoder counts.

- **Position or Distance:** encoder counts
- **Velocity:** 0.1 encoder counts per second
- **Acceleration:** 10 encoder counts per second²
- **Deceleration:** 10 encoder counts per second²
- **Jerk:** 100 encoder counts per second³

3.8.2: User-Defined Units

The Amplifier Object property [CountsPerUnit \(p. 49\)](#) can store a scaling factor for converting between an amplifier's default units (encoder counts) and user-defined units. Default = 1. For example, with a 5-miron encoder on a linear motor, to program in millimeters, set CountsPerUnit = 200, since there are 200 encoder counts in one millimeter.

3.9: Stepnet Amplifiers

3.9.1: Stepper and Servo Modes

On power up/reset Stepnet amplifiers start in stepper mode. If it is necessary to switch a Stepnet amplifier from step to servo mode, set the property [AmpMode](#) (p. 49) to one of the servo modes listed in [Modes of Operation for CML_AMP_MODE](#) (p. 50). This should be done immediately after amplifier initialization.

In the following example, the amplifier is initialized and then the amplifier's mode of operation is switched to the servo Can profile mode:

```
ampObj.Initialize(canOpen, 1)
ampObj.AmpModeWrite = CMLCOMLib.CML_AMP_MODE.AMPMODE_SERVO_CAN_PROFILE
```

3.9.2: Open Loop Stepper Mode Actual Position and Velocity

When running open loop stepper mode, actual position and actual velocity readings remain at zero. The motor's commanded position can be monitored with `CMLCOMLib.AmpObj.PositionCommand` (Units: microsteps). The motor's commanded velocity can be monitored with `CMLCOMLib.AmpObj.TrajectoryVel` (Units microsteps/second).

When the amplifier is disabled, `PositionCommand` goes to zero because the amplifier cannot tell if the motor moves while disabled. As long as the amplifier is enabled, relative and absolute moves can be made based on `PositionCommand`.

3.9.3: Stepper Mode with Encoder Actual Position and Velocity

When running in stepper mode with an encoder, actual position can be monitored with `CMLCOMLib.AmpObj.PositionActual` (Units: microsteps). Actual velocity can be monitored with `CMLCOMLib.AmpObj.VelocityLoad` (Units microsteps/second).

NOTE: Actual velocity can also be monitored with `CMLCOMLib.AmpObj.VelocityActual`, but the units will be in encoder counts/second. This is not recommended, because user units will also be applied to this value.

APPENDIX

A: CANOPEN OBJECT

This appendix describes the CANopen network object.

NOTE: Unless otherwise stated, all properties described in this appendix have read/write access. All methods return an HRESULT. In the event of an error, CMO reports the error in the form of COM-compatible error objects. See [Error Handling \(p. 15\)](#).

A.1: CANopen

All the methods and properties described below are members of *CMLCOMLib.CANOpenObj*.

Method Initialize ()

Initializes the CANopen network.

Property ErrorFrameCounter As Long

Read-only. The number of error frames received over the CAN network since the last time the counter was cleared.

Method ClearErrorFrameCounter()

Clears the CAN error frame counter.

Property BitRate As CML_BIT_RATES

CANopen Bit Rate. If the Bit Rate is not set, CMO uses the default value of 1 Mb/s.

CML_BIT_RATES Bit Rate Values

Value (Const)	Description
BITRATE_1_Mbit_per_sec = 1000000	1 Mbit per second CAN bit rate
BITRATE_800_Kbit_per_sec = 800000	800Kbit per second CAN bit rate
BITRATE_500_Kbit_per_sec = 500000	500Kbit per second CAN bit rate
BITRATE_250_Kbit_per_sec = 250000	250Kbit per second CAN bit rate
BITRATE_125_Kbit_per_sec = 125000	125Kbit per second CAN bit rate
BITRATE_50_Kbit_per_sec = 50000	50Kbit per second CAN bit rate
BITRATE_20_Kbit_per_sec = 20000	20Kbit per second CAN bit rate

Property PortName As String

Port name for the CAN card. The port name is a combination of the CAN card name and the channel number as shown below. If the port name is not set, CMO uses channel 0 of the first supported CAN card found.

CAN Card	Channel	PortName
Copley	0	copley0
	1	copley1
Kvaser	0	kvaser0
National Instruments	0	ni0
Vector	0	vector0
IXXAT	0	ixxat0

APPENDIX

B: AMPLIFIER AND RELATED OBJECTS

This appendix details the amplifier object and other objects related to amplifier settings and status.

Note: Unless otherwise stated, all properties described in this appendix have read/write access. All methods return an HRESULT. In the event of an error, CMO reports the error in the form of COM-compatible error objects. See [Error Handling \(p. 15\)](#). Contents include:

Function Group	PAGE
B.1: AmpSettingsObj	20
B.2: Amplifier Initialization	21
B.3: Amplifier Information	21
B.4: Motor/Feedback Information	24
B.5: Save/Restore Amplifier Data	27
B.6: Node Guarding	27
B.7: Current Loop	27
B.8: Velocity Loop	29
B.9: Position Loop	30
B.10: Tracking Windows	31
B.11: Status, Events, and Faults	31
B.12: Amplifier Digital Inputs/Outputs	35
B.13: Amplifier Enable/Disable	39
B.14: Homing	40
B.15: Quick Stop	43
B.16: Point-to-Point Moves	44
B.17: Amplifier Events	45
B.18: Amplifier Trace Methods and Properties	46
B.19: Other Methods and Properties	49

B.1: AmpSettingsObj

B.1.1: Overview

AmpSettingsObj contains information about the amplifier's CANopen settings. All of the properties have both read and write access. The Amplifier Settings Object is used in the InitializeExt method of the Amplifier Object to customize the amplifier's CANopen settings.

The basic steps for using the AmpSettingsObj are:

- 1 Declare an AmpSettingsObj.
- 2 Create a new instance of it.
- 3 Change one or more properties of the AmpSettingsObj.
- 4 Call AmpObj's InitializeExt method and pass AmpSettingsObj as one of the parameters. See [InitializeExt](#) (p. 21).

B.1.2: AmpSettingsObj Methods and Properties

Each of the following properties is a member of *CMLCOMLib_AmpSettingsObj*.

Property guardTime As Integer

Node guarding guard time. This property gives the node-guarding period for use with this node. This is the period between node guarding request messages sent by the master controller. Units: milliseconds. Default: 0.

Property heartbeatPeriod As Integer

Configures the heartbeat period used by this amplifier to transmit its heartbeat message. If this property is set to zero, then the heartbeat protocol is disabled on this node. Units: milliseconds. Default: 0.

Property heartbeatTimeout As Integer

Additional time to wait before generating a heartbeat error. Units: milliseconds. Default: 0.

Property lifeFactor As Integer

Node guarding lifetime factor. The lifetime factor is treated as a multiple of the guard time. If this property and the node guard time are both non-zero, and the heartbeatTime is zero, then node guarding will be setup for the amplifier. Units: milliseconds. Default = 3.

Property resetOnInit As Boolean

If *True*, the amplifier will be reset when it is initialized. This has the advantage of clearing out any fault conditions and putting the amplifier in a known state. Default: False.

Property enableOnInit As Boolean

Enable amplifier at init time. If true, then the amplifier will be enabled at the end of a successful initialization. If false, the amplifier will be disabled at the end of a successful initialization. Default: True

Property synchID As Long

Synch object CAN message ID. This is the message ID used for the synch message. Default: 128 (0x00000080)

Property synchPeriod As Long

Synch object period. The synch object is a message that is transmitted by one node on a CANopen network at a fixed interval. This message is used to synchronize the devices on the network. Units: microseconds. Default: 10000.

Property synchProducer As Boolean

If true, this node will produce synch messages. If 'synchUseFirstAmp' property is set to true, this property will not be used and will be overwritten during initialization. Default: false.

Property synchUseFirstAmp As Boolean

Use first initialized amplifier as synch producer. If this setting is true (default), then the first amplifier to be initialized will be set as the synch producer, and all other amplifiers will be setup as synch consumers. Default: true

Property timeStampID As Long

High-resolution time stamp CAN ID. The time stamp is a PDO that is generated by the synch producer. It is used to synchronize the clocks of the amplifiers. Setting this to zero will disable the time stamp message. Default: 384 (0x00000180).

B.2: Amplifier Initialization

Each of these amplifier initialization methods is a member of *CMLCOMLib.AmpObj*.

Method Initialize (canOpenObj As ICANopenObj, nodeId As Integer)

Initializes the amplifier with the CANOpenObj, the specified node ID, and default Amplifier Settings.

Parameters:

canOpenObj: An instance of a CanOpenObj that has already been initialized.

nodeId: The node ID of the amplifier.

Method InitializeExt(canOpenObj As ICANopenObj, nodeId As Integer, ampSettingsObj As IAmpSettingsObj)

Initializes amplifier with the CANOpenObj, the specified node ID, and the AmpSettingsObj. See [B.1: AmpSettings \(p. 20\)](#).

Parameters:

canOpenObj: An instance of a CanOpenObj that has already been initialized.

nodeId: The node ID of the amplifier.

ampSettingsObj: An instance of an AmpSettingsObj with customized settings.

Method Relnit()

Re-initializes an amplifier, using the same initialize method that was previously used.

B.3: Amplifier Information

B.3.1: Amplifier Information-Related Amplifier Object Properties

The following amplifier property is a member of *CMLCOMLib.AmpObj*.

Property AmplInfo As CMLCOMLib.AmplInfoObj

Read-only. Contains the AmplInfoObj. See [Objects Contained by AmpObj \(p. 12\)](#) and [B.3.2 AmplInfoObj](#), below.

B.3.2 AmplInfoObj

Each of the following Read-Only properties is a member of *CMLCOMLib.AmplInfoObj*. An instance of this object is obtained from the AmpObj.

Property crntCont As Double

Amplifier continuous current rating. Units: A.

Property crntPeak As Double

Amplifier peak current rating. Units: A.

Property crntScale As Integer

Current scaling factor.

Property crntTime As Double

Time at amplifier peak current. Units: seconds.

Property mfgInfo As String

Amplifier's manufacturing information string.

Property mfgName As String

Name of the amplifier manufacturer.

Property mfgWeb As String

Web address of the manufacturer.

Property model As String

Model number string.

Property modes As Long

Supported modes of operation as described in *CANopen Profile for Drives and Motion Control (DSP 402)*.

Bits	Mode Description
0	Profile position mode
1	Profile velocity mode
5	Homing mode
6	Interpolated position mode

Continued...

...*AmplInfoObj*, continued

Property pwm_dbcont As Integer PWM deadband at continuous current. Units: servo cycles.	
Property pwm_dbzero As Integer PWM deadband at zero current. Units: servo cycles.	
Property pwm_off As Integer PWM off time. Units: tens of nanoseconds.	
Property pwmPeriod As Double PWM period. Units: seconds.	
Property refScale As Integer Reference scaling factor.	
Property serial As Long Serial number of the amplifier's printed circuit board.	
Property servoPeriod As Double Servo period. Units: seconds.	
Property swVer As String The firmware version number in the amplifier.	
Property tempHyst As Double Temperature hysteresis for over temperature fault. Units: degrees C.	
Property tempMax As Double Set point for over temperature fault. Units: degrees C.	
Property type As Integer Amplifier type.	
Value	Amplifier Type
512	Accelnet Module
513	Xenus
515	Accelnet Panel
518	Xenus, resolver version
519	Xenus, with emulated encoder output
521	Accelnet Micro Panel
523	Accelnet Panel, with emulated encoder output
524	Accelnet Micro Module
526	Xenus, with differential digital inputs
527	Accelnet Panel
528	Accelnet Micro Panel, analog encoder version
576	Stepnet Module
578	Stepnet Panel
579	Stepnet Micro Module
Property voltMax As Double Set point for an over voltage fault. Units: 0.1V.	
Property voltMin As Double Set point for under voltage fault. Units: 0.1 V.	
Property voltScale As Integer: Voltage scaling factor. Units: 0.1 V.	
Property aencScale As Integer The analog encoder-scaling factor.	
Property regenPeak As Integer The internal regen circuit peak current limit Units: 0.01 A.	

Continued...

...AmplInfoObj, continued

Property regenCont As Integer

The internal regen circuit continuous current limit. Units: 0.01 A.

Property regenTime As Integer

The internal regen circuit time at peak current. Units: milliseconds.

Property voltHyst As Double

Bus voltage hysteresis for over voltage shutdown. Units: 0.1 Volts.

B.4: Motor/Feedback Information

B.4.1: Motor/Feedback-Related Amplifier Object Methods and properties

Each of the following motor/feedback methods and properties is a member of *CMLCOMLib.AmpObj*.

Method ReadAnalogFeedback(Sin As Integer, Cos As Integer)

Reads the raw voltage on the two analog feedback inputs. Units: 0.1 mV.

Property HallState As Integer

Read-only. Gets the current digital hall sensor state. The hall state is the value of the hall sensors after any adjustments have been made to them, based on the [Property hallWiring](#) property of MotorInfoObj2. See [B.4.2: MotorInfoObj](#) (p. 24).

Property PhaseAngle As Integer

Read-only. Gets the motor phase angle. The phase angle describes the motor's electrical position with respect to its windings. Units: degrees.

Property MotorInfoObj2 As CMLCOMLib.MotorInfoObj

This property contains the MotorInfoObj. See [Objects Contained by AmpObj](#) (p. 12) and [B.4.2: MotorInfoObj](#), below.

B.4.2: MotorInfoObj2

Each of the following Motor/Feedback properties is a member of *CMLCOMLib.MotorInfoObj2*. An instance of this object is obtained from the AmpObj.

Property backEMF As Double

Back EMF constant. Units: Rotary: V/KRPM, Linear: V/m/S.

Property brakeDelay As Integer

Delay between applying brake & disabling PWM. Units: milliseconds.

Property brakeVel As Double

Velocity below which the brake will be applied. User-defined units/second; see [Units](#) (p. 15).

Property ctsPerRev As Long

Encoder counts/revolution. Rotary motors only.

Property eleDist As Long

Motor electrical distance. Linear motors only. Units: encoder units/electrical phase.

Property encRes As Integer

Encoder resolution. Linear motors only. Units: encoder units/count.

Property encReverse As Boolean

Reverse encoder direction if *True*.

Property encType As Integer

Encoder type.

Value	Description
0	Incremental quadrature encoder.
1	No encoder.
2	Analog encoder.
3	Secondary quad encoder from input lines.
4	Low frequency analog encoder. For use with Copley ServoTube motor.
5	Resolver.

Property encUnits As Integer

Encoder units. Linear motor only.

Property hallOffset As Integer

Hall offset. Units: degrees.

Continued...

...MotorInfoObj, continued

Property hallType As Integer

Type of hall sensors on the motor.

Value	Description
0	No hall sensors available.
1	Digital hall sensors.
2	Analog hall sensors.

Property hallWiring As Integer

Hall wiring code. This bit-mapped value defines the wiring of the hall sensors.

Bit	Description
0-2	The hall wiring code (see below).
3	Reserved.
4	Invert W hall input if set.
5	Invert V hall input if set.
6	Invert U hall input if set.
7	Reserved.
8	Swap analog halls if set.
9-15	Reserved.

The hall wiring codes define the order of the hall connections. Hall code ordering:

Hall Wiring Code	Description
0	U V W
1	U W V
2	V U W
3	V W U
4	W V U
5	W U V
6,7	Reserved

Property hallVelocityShift as Integer

This value is used to scale up the calculated velocity in Hall velocity mode (Halls used for feedback in velocity mode). It specifies a left shift value for the position and velocity information calculated in that mode.

Property hasBrake As Boolean

Motor has a brake if True.

Property inductance As Double

Motor inductance (Henrys).

Property inertia As Double

Inertia. Units: Kg-cm².

Property mfgName As String

Name of the motor manufacturer.

Property model As String

Motor model number.

Property mtrReverse As Boolean

Reverse motor wiring if true.

Property poles As Integer

Number of pole pairs (number of electrical phases) per rotation. Rotary motors only.

Property resistance As Double

Motor resistance. Units: Ω.

Continued...

*...MotorInfoObj, continued***Property stopTime As Integer**

Delay between disabling amplifier and applying brake. During this time, amplifier attempts to stop motor.
Units: milliseconds.

Property tempSensor As Boolean

Motor has a temperature sensor.

Property trqConst As Double

Torque constant (rotary), Force constant (linear). Units: Rotary: Newton Meters/A; Linear: Newtons/A.
For stepper motors, the value returned is Rated Torque/Rated Current.

Property trqCont As Double

Continuous torque (rotary), Continuous force (linear). Units: Rotary: Newton Meters; Linear: Newtons.
This parameter is not used for stepper motors.

Property trqPeak As Double

Peak torque (rotary), Peak force (linear), Rated Torque (stepper motors).
Units: Rotary, Stepper: Newton Meters; Linear: Newtons.

Property type As Integer

Motor type.

Value	Description
0	Rotary motor.
1	Linear motor.

Property velMax As Double

Maximum motor velocity. User-defined units/second; [Units \(p. 15\)](#).

Property encShift As Integer

Analog feedback interpolation value (used only with Analog feedback).

Property ndxDist As Long

Index mark distance (reserved for future use).

Property stepsPerRev As Long

Microsteps/revolution (used for Stepmet amplifiers).

Property loadEncType As Integer

Load Encoder Type:

Bit	Description
0-2	Encoder type value (see below).
3	Reserved.
4	Linear if set, rotary if clear.

Load encoder type values:

Value	Description
0	No load encoder present.
1	Primary (differential) quadrature encoder.
2	Analog encoder.
3	Secondary quadrature encoder from input lines.
4	Low-frequency analog encoder. For use with Copley ServoTube motor.
5	Resolver

Property loadEncRes As Long

Load Encoder Resolution: This is encoder counts/rev for rotary encoders and nanometers/count for linear encoders.

Property loadEncReverse As Boolean

Load Encoder Reverse: Reverse load encoder direction if true.

Property resolverCycles As Integer

Number of resolver cycles per motor revolution.

B.5: Save/Restore Amplifier Data

The following methods are used to save and restore amplifier data. They are members of *CMLCOMLib.AmpObj*

Method LoadFromFile (name As String, line As Long)

Loads specified amplifier data file. Presently supports loading *.ccx files created by CME 2 version 3.1 and later.

NOTE: This method loads the file into the amplifier's RAM (except the motor data, which exists in Flash only). To save the data to the amplifier's Flash, call the SaveRamToFlash method (see below).

Parameters:

name: Name (and optionally path) of the file to load.

line: If not NULL, the last line number read from the file is returned here.

Method SaveRamToFlash()

Saves parameters stored in the amplifiers volatile RAM memory to non-volatile flash memory

B.6: Node Guarding

The following methods, members of *CMLCOMLib.AmpObj*, are used to control node guarding.

Method StartGuarding(guardTime As Integer, lifeFactor As Integer)

Starts node guarding with the specified guard time and life factor. Units: time: milliseconds, lifeFactor: none

Method StopGuarding()

Disables node guarding & heartbeat monitoring.

Method ClearNodeGuardEvent()

Attempts to clear a node guarding event condition.

B.7: Current Loop

B.7.1: Current Loop-Related Amplifier Object Properties

The following current loop methods and properties are members of *CMLCOMLib.AmpObj*.

Property CurrentLimited As Integer

Read-only. Gets the limited motor current. The commanded current is passed to a current limiter. The output of the current limiter is the limited current, which is passed as an input to the current loop. Units: 0.01 A.

Property CurrentCommand As Integer

Read-only. This current is the input to the current limiter. Units: 0.01 A.

Property CurrentActual As Integer

Read-only. Gets the actual motor current. This current is based on the amplifier's current sensors, and indicates the portion of current that is being used to generate torque in the motor. Units: 0.01 A.

Method ReadMotorCurrent (Ucurrent As Integer, Vcurrent As Integer)

Reads the actual current values read directly from the amplifier's current sensors. Note that if the motor wiring is being swapped in software, the U and V reading will be swapped. Units: 0.01 A.

Property TorqueTarget As Integer

In profile torque mode, this property is an input to the amplifier's internal trajectory generator. Any change to the target torque triggers an immediate update to the trajectory generator. Units: 0.01 A.

Property TorqueDemand As Integer

Read-only. In Profile Torque mode, this is the output value of the torque limiting function. Units: 0.01 A.

Property TorqueActual As Integer

Read-only. Instantaneous torque in the motor. Units: 0.01 A.

Property TorqueSlope As Integer

Torque acceleration or deceleration. Units: 0.01 A.

Property CurrentLoopSettings As CMLCOMLib.CurrentLoopSettings

Contains the CurrentLoopSettings object. Units: 0.01 A. See [B.7.2: CurrentLoopSettings Object \(p. 28\)](#).

B.7.2: CurrentLoopSettings Object

The following current loop properties are members of *CMLCOMLib*. *CurrentLoopSettings*. An instance of this object is obtained from the *AmpObj*.

Property CntLoopKp As Integer Current loop proportional gain value.
Property CntLoopKi As Integer Current loop integral gain value.
Property CntLoopCntOffset As Integer Current loop offset value. Units 0.01 A.
Property CntLoopPeakCntLim As Integer Peak current limit. Maximum current that can be applied to the load at any time. In stepper mode, this is the boost current. Units: 0.01 A.
Property CntLoopContCntLim As Integer Continuous current limit. Max current that can continuously be applied to load. In stepper mode, this is the run current. Units: 0.01 A.
Property CntLoopPeakCntTime As Integer Time at peak current limit. In stepper mode, this is time at boost current. Units: milliseconds.
Property CntLoopStepHoldCnt As Integer The Stepper Hold Current. Current used to hold the motor at rest. Units: 0.01A
Property CntLoopStepRunToHoldTime As Integer The Stepper Run To Hold Time. The period of time, beginning when a move is complete, to when the output current is switched to the hold current. Units: milliseconds.
Property CntLoopVolControlDelayTime As Integer The Voltage Control Delay Time. If set to zero feature is disabled. Units: milliseconds.

B.8: Velocity Loop

B.8.1: Velocity Loop-Related Amplifier Object Properties

The following velocity loop properties are members of *CMLCOMLib.CML_AmplInfo*.

Property VelocityLimited As Double

Read-only. Gets the limited velocity, which is the result of applying the velocity limiter to the commanded velocity. User-defined units/second; see [Units \(p. 15\)](#).

Property VelocityCommand As Double

Read-only. Gets the commanded velocity. The commanded velocity is the velocity value passed to the velocity limiter, and, from there, to the velocity control loop. User-defined units/second; see [Units \(p. 15\)](#).

Property VelocityActual As Double

Read-only. The motor velocity is calculated by the amplifier based on the change in position. For dual encoder systems, the load velocity can be queried by reading the VelocityLoad property. User-defined units/second; see [Units \(p. 15\)](#).

Property VelocityLoad As Double

Read-only. The load velocity is estimated by the amplifier based on the change in position seen at the load encoder. For dual encoder systems, the motor velocity can be queried reading the VelocityActual property. User-defined units/second; see [Units \(p. 15\)](#).

Property VelocityLoopSettings As CMLCOMLib.VelocityLoopSettings

This property contains the VelocityLoopSettings object. See [Objects Contained by AmpObj \(p. 12\)](#) and [B.8.2: VelocityLoopSettings Object](#), below.

B.8.2: VelocityLoopSettings Object

The following velocity loop properties are members of *CMLCOMLib.VelocityLoopSettings*. An instance of this object is obtained from the AmpObj.

Property VelLoopKp As Integer

Velocity loop proportional gain value.

Property VelLoopKi As Integer

Velocity loop integral gain value.

Property VelLoopKaff As Integer

Velocity loop acceleration feed forward value.

Property VelLoopShift As Integer

Velocity shift value. After velocity loop is calculated, the result is right-shifted this many times to arrive at the commanded current value. This allows the velocity loop gains to have reasonable values for high-resolution encoders.

Property VelLoopMaxVel As Double

Velocity loop maximum allowed velocity. Limits the velocity command before the velocity loop uses it to calculate output current. User-defined units/second; see [Units \(p. 15\)](#).

Property VelLoopMaxAcc As Double

Velocity loop maximum acceleration limit. Limits the rate of change of the velocity command input to the velocity loop. It is used when the magnitude of the command is increasing. User-defined units/second²; see [Units \(p. 15\)](#).

Property VelLoopMaxDec As Double

Velocity loop maximum deceleration limit. Limits the rate of change of the velocity command input to the velocity loop. It is used when the magnitude of the command is decreasing. User-defined units/second²; see [Units \(p. 15\)](#).

Property VelLoopEstopDec

Deceleration used for emergency stop. Setting this value to zero indicates that the deceleration is unlimited. User-defined units/second²; see [Units \(p. 15\)](#).

B.9: Position Loop

B.9.1: Position Loop-Related Amplifier Object Properties

The following position loop properties are members of *CMLCOMLib AmpObj*.

Property PositionError As Double

The position error (difference between position command and actual position). User-defined units; see [Units \(p. 15\)](#).

Property PositionCommand As Double

The instantaneous position command. This position is the command input to the servo loop. The position command is calculated by the trajectory generator and updated every servo cycle. User-defined units; see [Units \(p. 15\)](#).

Property PositionActual As Double

The actual position used by the servo loop. For dual encoder systems, this will be the load encoder position. To get the motor encoder position on such a system, read the PositionMotor property. User-defined units; see [Units \(p. 15\)](#).

Property PositionMotor As Double

The actual motor position. For single encoder systems, this value is identical to the PositionActual property. For dual encoder systems, this function returns the actual motor position and the PositionActual property may be used to get the load encoder position. User-defined units; see [Units \(p. 15\)](#).

Property PositionLoopSettings2 As CMLCOMLib.PositionLoopSettings2

This property contains the PositionLoopSettings2 object. See [Objects Contained by AmpObj \(p. 12\)](#) and [B.9.2: PositionLoopSettings2 Object](#), below.

B.9.2: PositionLoopSettings2 Object

The following position loop properties are members of *CMLCOMLib. PositionLoopSettings2*. An instance of this object is obtained from the AmpObj.

Property PosLoopKp As Integer

Position loop proportional gain value.

Property PosLoopKvff As Integer

Position loop velocity feed forward value.

Property PosLoopKaff As Integer

Position loop acceleration feed forward value.

Property PosLoopScale as Integer

The output of the position loop is multiplied by this value before being passed to the velocity loop. This scaling factor is calculated such that a value of 100 is a 1.0 scaling factor. This parameter is most useful in dual loop systems.

B.10: Tracking Windows

B.10.1: Tracking Windows - Related Amplifier Object Properties

The following amplifier property is a member of *CMLCOMLib.AmpObj*.

Property TrackingWindows As CMLCOMLib.TrackingWindows

This property contains the TrackingWindows object. See [Objects Contained by AmpObj](#) (p. 12) and [B.10.2 TackingWindows Object](#), below.

B.10.2 TackingWindows Object

Each of the following Amplifier Settings is a member of *CMLCOMLib.TrackingWindows*. An instance of this object is obtained from the *AmpObj*.

Property PositionErrorWindow As Double

Position error window. If the absolute value of the motor's position error exceeds this value, a tracking error occurs. The amplifier aborts move in progress and stops the motor with the velocity loop. User-defined units; see [Units](#) (p. 15).

Property PositionWarnWindow As Double

Position warning window. If the absolute value of the position error exceeds this value, then a tracking warning will result. A tracking warning causes a bit in the amplifier's status to be set. User-defined units; see [Units](#) (p. 15).

Property SettlingWindow As Double

Position settling window. An amplifier is settled in position after a move when its absolute position error value has been within the settling window for a time greater then the settling time. User-defined units; see [Units](#) (p. 15).

Property SettlingTime As Integer

Position settling time value. An amplifier is settled in position after a move when its absolute position error value has been within the settling window for a time greater then the settling time value. Units: milliseconds.

Property VelocityWarnWindow As Double

Velocity warning window. If the absolute value of the velocity error exceeds this value, then a velocity warning results. A velocity warning causes a bit in the amplifier's status to be set. User-defined units; see [Units](#) (p. 15).

Property VelocityWarnTime As Integer

Velocity warning window time value. If velocity error exceeds velocity warning window, a bit is set in the amplifier status word. Bit is not cleared until velocity error stays within warning window for at least this long. Units: milliseconds.

B.11: Status, Events, and Faults

Amplifier status and fault information can be accessed using the following methods and properties of *CMLCOMLib.AmpObj*.

B.11.1: Amplifier Status Register Methods

These methods read the amplifier's status registers (CML_EVENT_STATUS).

Method ReadEventStatus (eventStatus As CML_EVENT_STATUS)

Read amplifier's event status register. This is the main internal register, used to describe the amplifier's current state.

Method ReadEventSticky (eventSticky As CML_EVENT_STATUS)

Reads the amplifier's 'sticky' event status register, which is a copy of the amplifier's event status register. The bits of this register are set normally, but only cleared when the register is read (i.e., the bits are 'sticky'). For a description of the event status register, see [B.11.2: Amplifier Event Status Register Values](#) (p32).

Method ReadEventLatch (eventLatch As CML_EVENT_STATUS)

Reads the latched version of the amplifier's event status register, which is a copy of the amplifier's event status register. The bits of this register are set normally, but only cleared in response to an amplifier reset or power cycle or by calling *ClearFaults* (i.e., the bits are latched). For a description of the event status register, see [B.11.2: Amplifier Event Status Register Values](#) (p32).

B.11.2: Amplifier Event Status Register Values

Bits in the Event Status register describes various amplifier status conditions, as described below.

Value (Const)	Bit	Description
EVENT_STATUS_SHORT_CIRCUIT = 1	0	Amplifier short circuit.
EVENT_STATUS_AMPLIFIER_TEMPERATURE = 2	1	Amplifier over temperature.
EVENT_STATUS_OVER_VOLTAGE = 4	2	Amplifier over voltage.
EVENT_STATUS_UNDER_VOLTAGE = 8	3	Amplifier under voltage.
EVENT_STATUS_MOTOR_TEMPERATURE = 16	4	Motor over temperature.
EVENT_STATUS_ENCODER_POWER = 32	5	Encoder power error.
EVENT_STATUS_PHASE_ERROR = 64	6	Phasing error.
EVENT_STATUS_CURRENT_LIMIT = 128	7	Current limited.
EVENT_STATUS_VOLTAGE_LIMIT = 256	8	Voltage limited.
EVENT_STATUS_POSITIVE_LIMIT = 512	9	Positive limit is active.
EVENT_STATUS_NEGATIVE_LIMIT = 1024	10	Negative limit is active.
EVENT_STATUS_DISABLE_INPUT = 2048	11	Hardware disabled (enable pin not set).
EVENT_STATUS_SOFTWARE_DISABLE = 4096	12	Disabled due to software request.
EVENT_STATUS_STOP = 8192	13	Try to stop motor (after disable, before brake).
EVENT_STATUS_BRAKE = 16384	14	Brake actuated.
EVENT_STATUS_PWM_DISABLE = 32768	15	PWM outputs disabled.
EVENT_STATUS_SOFTWARE_LIMIT_POSITIVE = 65536	16	Positive software limit reached.
EVENT_STATUS_SOFTWARE_LIMIT_NEGATIVE = 131072	17	Negative software limit reached.
EVENT_STATUS_TRACKING_ERROR = 262144	18	Tracking error.
EVENT_STATUS_TRACKING_WARNING = 524288	19	Tracking warning.
EVENT_STATUS_RESET = 1048576	20	Amplifier has been reset.
EVENT_STATUS_POSITON_WRAP = 2097152	21	Encoder position wrapped (rotary) or hit limit (linear).
EVENT_STATUS_FAULT = 4194304	22	Latching fault in effect.
EVENT_STATUS_VELOCITY_LIMIT = 8388608	23	Velocity is at limit.
EVENT_STATUS_ACCELERATION_LIMIT = 16777216	24	Acceleration is at limit.
EVENT_STATUS_TRACKING_WINDOW = 33554432	25	Not in tracking window if set.
EVENT_STATUS_HOME = 67108864	26	Home switch is active.
EVENT_STATUS_MOVING = 134217728	27	Trajectory generator active OR not yet settled.
EVENT_STATUS_VELOCITY_WIN = 268435456	28	Velocity error outside of velocity window when set.
EVENT_STATUS_PHASE_INIT = 536870912	29	Set when using algorithmic phase initialize mode and the phase is not initialized.
	30-31	Undefined

B.11.3: Amplifier Event Register Methods

The following member of *CMLCOMLib.AmpObj* is used to read the amplifier's event register.

Method ReadEventMask (eventMask As CML_AMP_EVENT)

Reads the current state of the amplifier's event register. The event mask is a bit-mapped variable that describes the state of the amplifier. The contents of this variable are built up from several different amplifier status words. For a description of masking, see [G.1: Masking \(p. 67\)](#). Event values are described below.

B.11.4: Amplifier Event Register Values

Bits in the Amp Event register describes various amplifier states, as described below.

Value (Const)	Bit	Description
AMPEVENT_MOVE_DONE = 1	0	Set when a move is finished and the amplifier has settled in to position at the end of the move. Cleared when a new move is started.
AMPEVENT_TRAJECTORY_DONE = 2	1	Set when the trajectory generator finishes a move. The motor may not have settled into position at this point. Cleared when a new move is started.
AMPEVENT_NODEGUARD = 4	2	A node guarding (or heartbeat) error has occurred. This bit is set when the error occurs, and is cleared by a call to the function ClearNodeGuardEvent (p. 27) .
AMPEVENT_START_ACKNOWLEDGE = 8	3	The Amplifier Object uses this event bit internally. It is set when the amplifier acknowledges a new move start.
AMPEVENT_FAULT = 16	4	A latching amplifier fault has occurred. The specifics of what caused the fault can be obtained by calling ReadFaults (p. 34) and the fault conditions cleared by calling ClearFaults (p. 34) .
AMPEVENT_ERROR = 32	5	A non-latching amplifier error has occurred.
AMPEVENT_POSITION_WARNING = 64	6	The amplifier's absolute position error is greater then the window set with PositionWarnWindow (p. 31) .
AMPEVENT_POSITION_WINDOW = 128	7	The amplifier's absolute position error is greater then the window set with SettlingWindow (p. 31) .
AMPEVENT_VELOCITY_WINDOW = 256	8	The amplifier's absolute velocity error is greater then the window set with VelocityWarnWindow (p. 31) .
AMPEVENT_DISABLED = 512	9	The amplifier's outputs are disabled. The reason for the disable can be determined by ReadEventStatus (p. 31) , which reads the event status word described in B.11.2: Amplifier Event Status Register Values (p. 32) .
AMPEVENT_POSITIVE_LIMIT = 1024	10	The positive limit switch is active.
AMPEVENT_NEGATIVE_LIMIT = 2048	11	The negative limit switch is active.
AMPEVENT_SOFTWARE_LIMIT_POSITIVE = 4096	12	The positive software limit is active.
AMPEVENT_SOFTWARE_LIMIT_NEGATIVE = 8192	13	The negative software limit is active.
AMPEVENT_QUICKSTOP = 16384	14	The amplifier is presently performing a quick stop sequence.
AMPEVENT_ABORT = 32768	15	The last profile was aborted without finishing
AMPEVENT_SOFTDISABLE = 65536	16	The amplifier is software disabled.
Undefined	17-30	
AMPEVENT_NOT_INITIALIZED = 2147483648	31	This amplifier's event mask has not yet been initialized (internal use only).

B.11.5: Amplifier Faults Methods and Properties

These methods and properties, members of *CMLCOMLib.AmpObj*, are associated with amplifier faults.

Property FaultMask As CML_AMP_FAULTS

Amplifier's fault mask. Fault mask identifies which conditions will be treated as latching faults by the amplifier. See [Amplifier Fault Values](#) (p. 34) for a list of faults. See [G.1: Masking](#) (p. 67) for an overview of the masking technique.

Method ReadFaults (faults As CML_AMP_FAULT)

Gets any active latched faults. See [Amplifier Fault Values](#) (p. 34) for a list of faults.

Method ClearFaults()

Clears amplifier faults. This function can be used to clear any latching faults on the amplifier. Faults are identified as latching using [FaultMask](#) (p. 34).

ClearFaults also clears tracking error conditions. Once a latched fault is detected in the amplifier, the amplifier will be disabled until the fault condition has been cleared. See [Amplifier Fault Values](#) (p. 34) for a list of faults.

B.11.6: Amplifier Fault Values

Bits in the Amp Faults register describes various amplifier faults, as described below.

Value (Const)	Bit	Description
FAULT_DATAFLASH = 1	0	Fatal hardware error: the flash data is corrupt.
FAULT_ADCCOFFSET = 2	1	Fatal hardware error: an A/D offset error has occurred.
FAULT_SHORT_CIRCUIT = 4	2	The amplifier detected a short circuit condition.
FAULT_AMP_TEMPERATURE = 8	3	The amplifier is over temperature.
FAULT_MOTOR_TEMPERATURE = 16	4	A motor temperature error was detected.
FAULT_OVER_VOLTAGE = 32	5	The amplifier bus voltage is over the acceptable limit.
FAULT_UNDER_VOLTAGE = 64	6	The amplifier bus voltage is below the acceptable limit.
FAULT_ENCODER_POWER = 128	7	Over current condition detected on output of the internal +5 Vdc supply used to power the feedback. Resolver or analog encoder not connected or levels out of tolerance.
FAULT_PHASE_ERROR = 256	8	Amplifier phasing error.
FAULT_TRACKING_ERROR = 512	9	Tracking error, the position error is too large.
FAULT_I ² T_LIMIT_ERROR = 1024	10	Current is limited by the I ² T algorithm.

B.12: Amplifier Digital Inputs/Outputs

Amplifier digital inputs/outputs are managed by these CMLCOMLib.AmpObj properties/methods.

B.12.1: Input Pin Methods

Each of the amplifier's digital inputs can be configured to perform an action. Note that one input can perform the same action as another (for instance, two hardware disable inputs). The methods below, members of *CMLCOMLib.AmpObj*, relate to the states and configuration of the inputs.

Property Inputs As Integer

Read-only. Gets the present hi/low states of the programmable inputs after debounce. The inputs are returned one per bit. The value of IN1 is returned in bit 0 (1 if high, 0 if low), IN2 in bit 1, etc.

Method ReadInputDebounce(input As Integer, time As Long)

Reads the debounce time for the specified input. This time specifies how long an input must remain stable at a new state before the amplifier recognizes the state.

Parameters:

input: The input to configure. Inputs are numbered starting from 0. Check amplifier data sheet for the number of inputs available.

time: The debounce time assigned to this input in milliseconds.

Method WriteInputDebounce(input As Integer, time As Long)

Writes the debounce time for the specified input. This time specifies how long an input must remain stable at a new state before the amplifier recognizes the state.

Parameters:

input: The input to configure. Inputs are numbered starting from 0. Check amplifier datasheet for the number of inputs available.

time: The debounce time assigned to this input in milliseconds.

Property IoPullup As Integer

State of the pull up/down resistors. Some Copley Controls amplifiers (see amplifier data sheet) have pull up/down resistors connected to a group of inputs. Each bit in the IoPullup property represents one pull up/down resistor; pull up/down resistor 1 is returned in bit 0, pull up/down resistor 2 is return in bit 2, etc. When the bit is set, the inputs connected to the resistor are pulled up to the high state when they are not connected. When the bit is cleared, the inputs are pulled down to a low state when they are not connected.

Method ReadInputConfig(input As Integer, config As CML_INPUT_PIN_CONFIG)

Gets the input configuration for the specified input. Each of the amplifier's inputs can be configured to perform some function.

Parameters:

input: Input to read. Inputs are numbered starting from 0. Check amplifier datasheet for number of inputs available.

config: Function assigned to the input.
See [B.12.2: Input Pin Configuration Settings](#) (p. 36).

Method WriteInputConfig(input As Integer, config As CML_INPUT_PIN_CONFIG)

Sets the input configuration for the specified input. Each of the amplifier's inputs can be configured to perform some function. *WriteInputConfig* configures the specified input to perform the specified function.

Parameters:

input: Input to read. Inputs are numbered starting from 0. Check amplifier datasheet for number of inputs available.

config: Function assigned to the input.
See [B.12.2: Input Pin Configuration Settings](#) (p. 36).

B.12.2: Input Pin Configuration Settings

The following values describe input pin configurations.

They can be read with [ReadInputConfig \(p. 35\)](#) and changed with [WriteInputConfig \(p. 35\)](#).

Value (Constant)	Description
INPUT_CONFIGURATION_NONE = 0	No function assigned to the input.
INPUT_CONFIGURATION_RESET_RISING = 2	Reset the amplifier on the rising edge of the input.
INPUT_CONFIGURATION_RESET_FALLING = 3	Reset the amplifier on the falling edge of the input.
INPUT_CONFIGURATION_POSITIVE_LIMIT_HIGH = 4	Positive limit switch; active high.
INPUT_CONFIGURATION_POSITIVE_LIMIT_LOW = 5	Positive limit switch; active low.
INPUT_CONFIGURATION_NEGATIVE_LIMIT_HIGH = 6	Negative limit switch, active high.
INPUT_CONFIGURATION_NEGATIVE_LIMIT_LOW = 7	Negative limit switch, active low.
INPUT_CONFIGURATION_MOTOR_TEMPERATURE_HIGH = 8	Motor temperature sensor; active high.
INPUT_CONFIGURATION_MOTOR_TEMPERATURE_LOW = 9	Motor temperature sensor, active low.
INPUT_CONFIGURATION_CLEAR_FAULTS_HIGH = 10	Clear faults on the rising edge; disable while high.
INPUT_CONFIGURATION_CLEAR_FAULTS_LOW = 11	Clear faults on the falling edge, disable while low.
INPUT_CONFIGURATION_RESET_DISABLE_RISING = 12	Reset on rising edge; disable while high.
INPUT_CONFIGURATION_RESET_DISABLE_FALLING = 13	Reset on falling edge; disable while low.
INPUT_CONFIGURATION_HOME_HIGH = 14	Home switch; active high.
INPUT_CONFIGURATION_HOME_LOW = 15	Home switch; active low.
INPUT_CONFIGURATION_DISABLE_HIGH = 16	Amplifier disable; active high.
INPUT_CONFIGURATION_DISABLE_LOW = 17	Amplifier disable; active low.
INPUT_CONFIGURATION_PWM_SYNCH = 19	PWM synchronization. Only for high speed inputs (see data sheet).
INPUT_CONFIGURATION_MOTION_ABORT_HIGH = 20	Abort move in progress; keep the amplifier enabled and servoing; active high.
INPUT_CONFIGURATION_MOTION_ABORT_LOW = 21	Abort move in progress; keep the amplifier enabled and servoing; active low.
INPUT_CONFIGURATION_HIGH_RES_ANALOG_DIVIDE_HIGH = 22	A high input causes the firmware to divide the level of the analog input signal by 8.
INPUT_CONFIGURATION_HIGH_RES_ANALOG_DIVIDE_LOW = 23	A low input causes the firmware to divide the level of the analog input signal by 8.

B.12.3: Output Pin Methods

Each of the amplifier's digital outputs can be configured to go active/inactive under different conditions. The methods and properties below, members of *CMLCOMLib.AmpObj*, relate to the states and configuration of the outputs.

Property Outputs As Integer

Reads or writes the present states (active/inactive) of the programmable outputs.

When this property is read, the current active/inactive state of all outputs is returned. Each output is represented by one bit in the returned value; bit 0 for output 1, bit 1 for output 2, etc.

When this property is written, it is used to control the active/inactive state of any outputs that are configured to operate in manual mode. Writing a 1 to a bit causes the corresponding output to become active; writing a 0 causes the output to become inactive. Bits corresponding to outputs that are not configured in manual mode are ignored.

Method ReadOutputConfig (output As Short, config As CML_OUTPUT_PIN_CONFIG, mask As Long)

Reads the configuration for the specified output.

NOTE: See the updated version of this method, [ReadOutputConfigExt \(p. 37\)](#).

Method ReadOutputConfigExt (output As Short, config As CML_OUTPUT_PIN_CONFIG, param1 As Integer, param2 As Long)

Reads the configuration for the specified output. For details, see [WriteOutputConfigExt \(p. 37\)](#).

Method WriteOutputConfig (output As Short, config As CML_OUTPUT_PIN_CONFIG, mask As Long)

Sets the configuration for the specified output. Each of the amplifier's outputs can be configured to event status tracking mode or manual mode, as specified by the *config* parameter.

Parameters:

- output: The output to configure. Outputs are numbered starting from 0. Check amplifier datasheet for the number of outputs available.
- config: The function to be assigned to this output.
See [B.12.5: Output Pin Configuration Values \(p. 38\)](#).
- mask: A 32-bit mask used to select which status bits the output should track. See [G.1: Masking \(p. 67\)](#). If the output is configured for manual mode (config=2 or 258), then the mask is not used and does not need to be specified.

NOTE: See the updated version of this method, [WriteOutputConfigExt \(p. 37\)](#).

Method WriteOutputConfigExt (output As Short, config As CML_OUTPUT_PIN_CONFIG, param1 As Integer, param2 As Integer)

Sets the configuration for the specified output. Each of the amplifier's outputs can be configured to event status tracking mode, position triggered mode, or manual mode, as specified by the *config* parameter.

Parameters:

- output: The output to configure. Outputs are numbered starting from 0. Check amplifier datasheet for the number of outputs available.
- config: The function to be assigned to this output.
See [B.12.5: Output Pin Configuration Values \(p. 38\)](#).
- param1: The function of param1 differs depending on the output pin configuration.
See [B.12.5: Output Pin Configuration Values \(p. 38\)](#).
- param2: The function of param2 differs depending on the output pin configuration.
See [B.12.5: Output Pin Configuration Values \(p. 38\)](#).

B.12.5: Output Pin Configuration Values

Each value described below specifies an output pin function, and whether the output will be active high or active low. These values are set and read using the methods described in [B.12.3: Output Pin Methods](#) (p. 37).

OUTPUT_CONFIGURATION_EVENT_STATUS_LOW = 0	
The output follows the amplifier's event status register and is active low. Parameters:	
param1	A 32-bit mask used to select which status bits the output should track.
param2	Has no meaning. Set to zero.
OUTPUT_CONFIGURATION_EVENT_STATUS_HIGH = 256	
The output follows the amplifier's event status register and is active high. Parameters:	
param1	A 32-bit mask used to select which status bits the output should track.
param2	Has no meaning. Set to zero.
OUTPUT_CONFIGURATION_EVENT_LATCH_LOW = 1	
The output follows the latched version of the amplifier's event status register and is active low. Parameters:	
param1	A 32-bit mask used to select which status bits the output should track.
param2	Has no meaning. Set to zero.
OUTPUT_CONFIGURATION_EVENT_LATCH_HIGH = 257	
The output follows the latched version of the amplifier's event status register and is active high. Parameters:	
param1	A 32-bit mask used to select which status bits the output should track.
param2	Has no meaning. Set to zero.
OUTPUT_CONFIGURATION_MANUAL_LOW = 2	
The output is manually controlled using Outputs (p. 37), and is active low. This method does not use parameters; set all parameters to zero.	
OUTPUT_CONFIGURATION_MANUAL_HIGH = 258	
The output is manually controlled using Outputs (p. 37), and is active high. This method does not use parameters; set all parameters to zero.	
OUTPUT_CONFIGURATION_TRAJECTORY_STATUS_LOW = 3	
The output pin follows bits in the amplifier's trajectory status register and is active low. Parameters:	
param1	A 32-bit mask used to select which status bits the output should track.
param2	Has no meaning. Set to zero.
OUTPUT_CONFIGURATION_TRAJECTORY_STATUS_HIGH = 259	
The output pin follows bits in the amplifier's trajectory status register and is active high. Parameters:	
param1	A 32-bit mask used to select which status bits the output should track.
param2	Has no meaning. Set to zero.
OUTPUT_CONFIGURATION_POSITION_WINDOW_LOW = 4	
The output goes active low if the actual motor position is greater than param1 and less than param2.	
param1	Low edge of position trigger window. Units: Counts.
param2	High edge of position trigger window. Units: Counts.
OUTPUT_CONFIGURATION_POSITION_WINDOW_HIGH = 260	
The output goes active high if the actual motor position is greater than param1 and less than param2.	
param1	Low edge of position trigger window. Units: Counts.
param2	High edge of position trigger window. Units: Counts.

Continued...

...Output Pin Configuration Values, continued:

OUTPUT_CONFIGURATION_MOTION_POSITIVE_LOW = 5	
The output goes active low when the motor actual position crosses in the low-to-high direction through the point specified in param1. The pin stays active for amount of time specified in param2.	
param1	Trigger position. Units: Counts.
param2	Output active time. Units: milliseconds.
OUTPUT_CONFIGURATION_MOTION_POSITIVE_HIGH = 261	
The output goes active high when the motor actual position crosses in the low-to-high direction through the point specified in param1. The pin stays active for amount of time specified in param2.	
param1	Trigger position. Units: Counts.
param2	Output active time. Units: milliseconds.
OUTPUT_CONFIGURATION_MOTION_NEGATIVE_LOW = 6	
The output goes active low when the motor actual position crosses in the high-to-low direction through the point specified in param1. The pin stays active for amount of time specified in param2.	
param1	Trigger position. Units: Counts.
param2	Output active time. Units: milliseconds.
OUTPUT_CONFIGURATION_MOTION_NEGATIVE_HIGH = 262	
The output goes active high when the motor actual position crosses in the high-to-low direction through the point specified in param1. The pin stays active for amount of time specified in param2.	
param1	Trigger position. Units: Counts.
param2	Output active time. Units: milliseconds.
OUTPUT_CONFIGURATION_TRIG_AT_POSITION_LOW = 7	
The output goes active low when the motor actual position crosses in any direction through the point specified in param1. The pin stays active for amount of time specified in param2.	
param1	Trigger position. Units: Counts.
param2	Output active time. Units: milliseconds.
OUTPUT_CONFIGURATION_TRIG_AT_POSITION_HIGH = 263	
The output goes active high when the motor actual position crosses in any direction through the point specified in param1. The pin stays active for amount of time specified in param2.	
param1	Trigger position. Units: Counts.
param2	Output active time. Units: milliseconds.
OUTPUT_CONFIGURATION_PWM_SYNC = 512	
PWM Synchronization. Note: Valid only on Output 0. This method does not use parameters; set all parameters to zero.	

B.13: Amplifier Enable/Disable

The following methods and properties of the AmpObj object are used to enable and disable the amplifier, and report on its state.

Property IsHardwareEnabled As Boolean	
Read-only. Returns True if amplifier's Enable input is currently active. Amplifier outputs may still be disabled due to error condition.	
Property IsSoftwareEnabled As Boolean	
Read-only. Returns True if amplifier is software enabled. Amplifier outputs may still be disabled due to error condition.	
Property IsPWMEabled	
Read-only. Returns true if the amplifier's PWM outputs are currently enabled.	
Method Enable()	
Software enables the amplifier.	
Method Disable()	
Software disables the amplifier.	

B.14: Homing

B.14.1: Homing-Related Amplifier Object Methods and Properties

The following homing methods and properties are members of *CMLCOMLib.AmpObj*.

Method GoHome()
Executes a homing move using the values set in the HomeSettings object.
Property IsReferenced As Boolean
Read-only. Returns True if successfully referenced (homed). When amplifier is powered up (or after a reset), it does not know the absolute position of the motor. After successful homing, the amplifier is considered referenced.
Property SoftPositionPosLimit As Double
Positive limit position. Any time the motors actual position is greater then this value, a positive software limit condition will be in effect on the amplifier. Software limits are enabled after the amplifier is referenced, and disabled by setting the positive limit equal to the negative limit.
Property SoftPositionNegLimit As Double
Negative limit position. Any time the motors actual position is less then this value, a negative software limit condition will be in effect on the amplifier. Software limits are enabled after the amplifier is referenced, and disabled by setting the positive limit equal to the negative limit.
Property HomeSettings As CMLCOMLib.HomeSettings
Contains the HomeSettings object. See Objects Contained by AmpObj (p. 12) and B.14.2: HomeSettings Object , below.

B.14.2: HomeSettings Object Properties

The following homing properties are members of *CMLCOMLib.HomeSettings*. An instance of this object is obtained from the AmpObj.

Property HomeOffset As Double
The home offset value. After the home position is found as defined by the home method, this offset will be added to it and the resulting position will be considered the zero position. User-defined units; see Units (p. 15).
Property HomeVelFast As Double
Velocity to use for fast moves during the home procedure. User-defined units/second; see Units (p. 15).
Property HomeVelSlow As Double
Velocity to use when seeking a sensor edge. User-defined units/second; see Units (p. 15).
Property HomeAccel As Double
Acceleration/deceleration value used for all homing procedure moves. User-defined units/second ² ; see Units (p. 15).
Property HomeCurrentLimit
Home current limit in hard stop mode, in which the amplifier drives the motor to the mechanical end of travel (hard stop). End of travel is recognized when the amplifier outputs the HomeCurrent for the HomeDelay time. Units: 0.01A.
Property HomeDelay
Delay used for homing to a hard stop in hard stop mode. Units: milliseconds.
Property HomeMethod As CML_HOME_METHOD
Gets the method used for homing the amplifier. See Property HomingMethods (p. 41).

Continued...

*...HomeSettingsObject, continued***Property HomingMethods**

Value (Const)	Description
CHOME_NEGATIVE_LIMIT_OUTTO_INDEX = 1	Move into the negative limit switch, then back to the first encoder index pulse beyond it. Index position is home.
CHOME_POSITIVE_LIMIT_OUTTO_INDEX = 2	Move into the positive limit switch, then back to the first encoder index pulse beyond it. Index position is home.
CHOME_POSITIVE_HOME_OUTTO_INDEX = 3	Move to a positive home switch, then back to the first encoder index outside the home region. Index position is home.
CHOME_POSITIVE_HOME_INTTO_INDEX = 4	Move to a positive home switch, and continue to the first encoder index inside the home region. Index position is home.
CHOME_NEGATIVE_HOME_OUTTO_INDEX = 5	Move to a negative home switch, then back to the first encoder index outside the home region. Index position is home.
CHOME_NEGATIVE_HOME_INTTO_INDEX = 6	Move to a negative home switch, and continue to the first encoder index inside the home region. Index position is home.
CHOME_LOWER_HOME_OUTSIDE_INDEX_POSITIVE = 7	Move to the lower side of a momentary home switch. Then find the first encoder index pulse outside the home region. If the home switch is not active when the home sequence starts, then the initial move will be positive.
CHOME_LOWER_HOME_INSIDE_INDEX_POSITIVE = 8	Move to the lower side of a momentary home switch. Then find the first encoder index pulse inside the home region. If the home switch is not active when the home sequence starts, then the initial move will be positive.
CHOME_UPPER_HOME_INSIDE_INDEX_POSITIVE = 9	Move to the upper side of a momentary home switch. Then find the first encoder index pulse inside the home region. If the home switch is not active when the home sequence starts, then the initial move will be positive.
CHOME_UPPER_HOME_OUTSIDE_INDEX_POSITIVE = 10	Move to the upper side of a momentary home switch. Then find the first encoder index pulse outside the home region. If the home switch is not active when the home sequence starts, then the initial move will be positive.
CHOME_UPPER_HOME_OUTSIDE_INDEX_NEGATIVE = 11	Move to the upper side of a momentary home switch. Then find the first encoder index pulse outside the home region. If the home switch is not active when the home sequence starts, then the initial move will be negative.
CHOME_UPPER_HOME_INSIDE_INDEX_NEGATIVE = 12	Move to the upper side of a momentary home switch. Then find the first encoder index pulse inside the home region. If the home switch is not active when the home sequence starts, then the initial move will be negative.
CHOME_LOWER_HOME_INSIDE_INDEX_NEGATIVE = 13	Move to the lower side of a momentary home switch. Then find the first encoder index pulse inside the home region. If the home switch is not active when the home sequence starts, then the initial move will be negative.
CHOME_LOWER_HOME_OUTSIDE_INDEX_NEGATIVE = 14	Move to the lower side of a momentary home switch. Then find the first encoder index pulse outside the home region. If the home switch is not active when the home sequence starts, then the initial move will be negative.
CHOME_NEGATIVE_LIMIT = 17	Move into the negative limit switch. The edge of the limit is home.

Continued...

...Property HomingMethods, continued

CHOME_POSITIVE_LIMIT = 18	Move into the positive limit switch. The edge of the limit is home.
CHOME_POSITIVE_HOME = 19	Move to a positive home switch. The edge of the home region is home.
CHOME_NEGATIVE_HOME = 21	Move to a negative home switch. The edge of the home region is home.
CHOME_LOWER_HOME_POSITIVE = 23	Move to the lower side of a momentary home switch. The edge of the home region is home. If the home switch is not active when the home sequence starts, then the initial move will be positive.
CHOME_UPPER_HOME_POSITIVE = 25	Move to the upper side of a momentary home switch. The edge of the home region is home. If the home switch is not active when the home sequence starts, then the initial move will be positive.
CHOME_UPPER_HOME_NEGATIVE = 27	Move to the upper side of a momentary home switch. The edge of the home region is home. If the home switch is not active when the home sequence starts, then the initial move will be negative.
CHOME_LOWER_HOME_NEGATIVE = 29	Move to the lower side of a momentary home switch. The edge of the home region is home. If the home switch is not active when the home sequence starts, then the initial move will be negative.
CHOME_INDEX_NEGATIVE = 33	Move in the negative direction until the first encoder index pulse is found. The index position is home.
CHOME_INDEX_POSITIVE = 34	Move in the positive direction until the first encoder index pulse is found. The index position is home.
CHOME_NONE = 35	Set the current position to home.
CHOME_HARDSTOP_OUTSIDE_INDEX_NEG = 252	Home to a hard stop. Move in the negative direction until the homing current has been reached. This current will be held until the homing delay has expired. Then move away from the hard stop until an index mark is located. The index position is home.
CHOME_HARDSTOP_OUTSIDE_INDEX_POS = 253	Home to a hard stop. Move in the positive direction until the homing current has been reached. This current will be held until the homing delay has expired. Then move away from the hard stop until an index mark is located. The index position is home.
CHOME_HARDSTOP_NEG = 254	Home to a hard stop. The motor will start running in the negative direction until the homing current has been reached. It will hold this current until the homing delay has expired. The actual position after that delay is home.
CHOME_HARDSTOP_POS = 255	Home to a hard stop. The motor will start running in the positive direction until the homing current has been reached. It will hold this current until the homing delay has expired. The actual position after that delay is home.

B.15: Quick Stop

Quick stops are controlled using these methods and properties of the `CMLCOMLib.AmpObj` object.

B.15.1: Quick Stop

The following properties and methods, members of `CMLCOMLib.AmpObj`, are used to configure the amplifier's quick stop action.

Property `QuickStopMode` As `CML_QUICK_STOP_MODE`

Quick stop mode. When the [QuickStop](#) command is issued, the amplifier stops the move in progress using the method defined by `QuickStopMode`.

Quick Stop Modes (`CML_QUICK_STOP`)

The quick stop modes chosen with `QuickStopMode` are described below.

Value (Const)	Description
<code>QSTOP_DISABLE = 0</code>	Disable the amplifier immediately.
<code>QSTOP_DECEL = 1</code>	Slow down using the profile deceleration (p. 44), and then disable.
<code>QSTOP_QUICKSTOP = 2</code>	Slow down using the quick stop deceleration (p. 43) then disable.
<code>QSTOP_ABRUPT = 3</code>	Slow down with unlimited deceleration then disable.
<code>QSTOP_DECEL_HOLD = 5</code>	Slow down using the profile deceleration (p. 44), and then hold. Amplifier must be disabled and re-enabled before motion is allowed.
<code>QSTOP_QUICKSTOP_HOLD = 6</code>	Slow down using the quick stop deceleration (p. 43) then hold. Amplifier must be disabled and re-enabled before motion is allowed.
<code>QSTOP_ABRUPT_HOLD = 7</code>	Slow down with unlimited deceleration then hold. Amplifier must be disabled and re-enabled before motion is allowed.

Property `QuickStopDec` As `Double`

Deceleration rate that the motor will use during a quick stop. User-defined units/second²; see [Units](#) (p. 15).

Method `QuickStop()`

Performs quick stop on axis using the [QuickStopMode](#) (p. 43) programmed in the amplifier.

B.15.2: Halt

The following properties and methods, members of `CMLCOMLib.AmpObj`, are used to configure the amplifier's halt action.

Property `HaltMode` As `CML_HALT_MODE`

Halt mode. When the amplifier's [HaltMove](#) command is issued, the amplifier stops the move in progress using the method defined by `HaltMode`. Halt modes are described below.

Halt Modes (`CML_HALT_MODE`)

The halt modes chosen with `HaltMode` are described below.

Value (Const)	Description
<code>HALT_DISABLE = 0</code>	Disable the amplifier immediately.
<code>HALT_DECEL = 1</code>	Slow down using the profile deceleration (p. 44).
<code>HALT_QUICKSTOP = 2</code>	Slow down using the quick stop deceleration (p. 43).
<code>HALT_ABRUPT = 3</code>	Slow down with unlimited deceleration.

Method `HaltMove()`

Halts current move using the [HaltMode](#) (p. 43) programmed in the amplifier. Halt modes are described above.

B.16: Point-to-Point Moves

B.16.1: Point-to-Point Move-Related Amplifier Methods and Properties

The following methods and properties, members of *CMLCOMLib.AmpObj*, can be used to control point-to-point moves.

Method MoveRel(distance As Double)

Performs a relative point-to-point move of the specified distance. Parameters:

distance: Trajectory distance. User-defined units; see [Units \(p. 15\)](#).

Method MoveAbs(position As Double)

Performs an absolute point-to-point move to the specified position. Parameters:

position: Trajectory target position. User-defined units; see [Units \(p. 15\)](#).

Property TargetPos As Double

Read-only. Reads the profile target position. User-defined units; see [Units \(p. 15\)](#).

Method WaitMoveDone(timeout As Long)

Waits for current move to finish. This method is blocking. When called, it will not return until either the event occurs, or the timeout expires. If a timeout occurs, CMO will report the timeout in the form of a COM compatible error object.

Parameters:

timeout: The timeout for the wait. If <0, then wait indefinitely. Units: milliseconds.

Property TrajectoryAcc As Double

Read-only. Gets the instantaneous commanded acceleration passed out of the trajectory generator. This acceleration is used by the position loop to calculate its acceleration feed forward term. User-defined units/second²; see [Units \(p. 15\)](#).

Property TrajectoryVel As Double

Read-only. Gets the instantaneous commanded velocity passed out of the trajectory generator. This velocity is used by the position loop to calculate its velocity feed forward term. User-defined units/second; see [Units \(p. 15\)](#).

Property ProfileSettings As CMLCOMLib.ProfileSettings

Contains the ProfileSettings object. See [Objects Contained by AmpObj \(p. 12\)](#) and [B.16.2: ProfileSettings Object](#), below.

B.16.2: ProfileSettings Object

The following point-to-point move properties are members of *CMLCOMLib.ProfileSettings*. An instance of this object is obtained from the AmpObj.

Property ProfileType As CML_PROFILE_TYPE

Motion profile type from the in [CML_PROFILE_TYPE Profile Types \(p. 44\)](#).

CML_PROFILE_TYPE Profile Types

These are the profile types that can be accessed using the [ProfileType](#) property.

Value (Const)

PROFILE_VELOCITY = -1

Description

Velocity profile. In this profile mode the velocity, acceleration and deceleration values are used. The position value is also used, but it only defines the direction of motion (positive if position is >= 0, negative if position is < 0).

Note: The PROFILE_VELOCITY type should be used only with the method [MoveAbs \(p. 44\)](#).

PROFILE_TRAP = 0

Trapezoidal profile. In this profile mode a position, velocity, acceleration, and deceleration may be specified.

PROFILE_SCURVE = 3

Jerk limited (S-curve) profile. In this mode, position, velocity, acceleration, and jerk (rate of change of acceleration) may be specified.

Property ProfileAcc As Double

The profile acceleration value that the motor uses when starting the move. User-defined units/second²; see [Units \(p. 15\)](#).

Property ProfileDecel As Double

The profile deceleration value that the motor uses when ending the move. This property is not used for S-curve profiles. User-defined units/second²; see [Units \(p. 15\)](#).

Continued...

*...ProfileSettings Object, continued***Property ProfileJerk As Double**

The jerk limit used with S-curve profiles. Jerk is rate of change of acceleration. Only used with S-curve profiles. User-defined units/second³; see [Units \(p. 15\)](#).

Property ProfileVel As Double

The profile velocity value that the motor attempts to reach during the move. User-defined units/second; see [Units \(p. 15\)](#).

Property Profile Abort

Deceleration value to use when aborting a running trajectory. User-defined units/second²; see [Units \(p. 15\)](#).

B.17: Amplifier Events

The following methods, members of *CMLCOMLib.AmpObj*, are used to monitor amplifier events and amplifier inputs.

Method CreateEvent (mask As CML_AMP_EVENT, condition As CML_EVENT_CONDITION) As EventObj

Creates an instance of EventObj, using specified parameters to monitor amplifier events. See [The Event Object \(p. 57\)](#).

Parameters:

- mask: The bit-mapped value that indicates which events are to be monitored. See [Amplifier Event Register Values \(p. 33\)](#).
- condition: The trigger condition for the events that will result in the event callback method being called (e.g. all events in the mask). See [Event Conditions \(p. 58\)](#).
- eventObject: The EventObj instance created by this method.

Method CreateInputEvent (mask As Integer, condition As CML_EVENT_CONDITION) As EventObj

Creates instance of EventObj that monitors the amplifier's digital inputs and sets it up using the specified parameters.

Parameters:

- mask: A bit-mapped value that indicates which digital input pin is to be monitored. Each corresponds to one input pin; bit 0 for input 0, bit 1 for input 1, etc.
- condition: The trigger condition for the events that will result in the event callback method being called (e.g. all events in the mask). See [Event Conditions \(p. 58\)](#).
- eventObject: The EventObj instance created by this method.

B.18: Amplifier Trace Methods and Properties

The following methods are used to configure and monitor the amplifier trace function.

B.18.1: Amplifier Trace Methods

The following amplifier trace methods are members of *CMLCOMLib.AmpObj*.

Method **ReadTraceStatus(status As CML_AMP_TRACE_STATUS, samplesCollected As Integer, maxSamples As Integer)**

Read the status of the amplifier's trace system. Parameters:

status: Information on whether the trace is currently running is returned in this parameter.

Value	Description
TRACE_STATUS_RUNNING = 1	Trace is currently collecting data.
TRACE_STATUS_TRIGGERED = 2	Trace has been triggered.
TRACE_STATUS_SAMPLED = 4	Trace is currently in sampled mode.
TRACE_STATUS_NODELAY = 8	Trace is configured to ignore initial delays.

samplesCollected: The total number of trace samples collected is returned here.

maxSamples: The maximum number of trace samples that will fit in the internal buffer is returned here. This value will change depending on how many trace channels are active and which variables are selected.

Method **ReadTraceRefPeriod(refPeriod As Long)**

Get the reference period used with the amplifier's trace mechanism. The amplifier internally samples its trace channels at integer multiples of this time. For example, if the amplifier's reference period is 100,000 nanoseconds, then setting the trace period to 12 would indicate that the amplifier should sample its internal variables every 1.2 milliseconds. Parameters:

refPeriod: The reference period is returned here. Units: refPeriod.

Method **WriteTracePeriod(tracePeriod As Integer)**

Set the period of time between trace samples. When the trace system is running, the amplifier will sample and store its internal variables this often. Note that this parameter specifies time in units of the amplifier's reference period. See **ReadTraceRefPeriod** for more information. Parameters:

tracePeriod: The trace period to be set. Units: refPeriod.

Method **ReadTracePeriod(tracePeriod As Integer)**

Get the period of time between trace samples. When the trace system is running, the amplifier will sample and store its internal variables this often. Note that this parameter specifies time in units of the amplifier's reference period. See **ReadTraceRefPeriod** for more information. Parameters:

tracePeriod: The trace period is returned here. Units: refPeriod.

Method **ReadTraceTrigger(type As CML_AMP_TRACE_TRIGGER, channel As Integer, level As Long, delay As Integer)**

Get the current configuration of the amplifier's trace trigger. See [B.18.2: Amplifier Trace Trigger Values \(p. 48\)](#) for more information about the trigger. Parameters:

type: The type of trigger to be used.

channel: Which trace channel to trigger on.

level: The trigger level.

delay: The delay between the occurrence of the trigger and the start of data collection.

Method **WriteTraceTrigger(type As CML_AMP_TRACE_TRIGGER, channel As Integer, level As Long, delay As Integer)**

Configure the amplifier's trace trigger. The trigger resembles the trigger on an oscilloscope. It allows an event to be specified which will cause the trace subsystem to start collecting data. Most trigger types watch one of the trace channels and constantly compare its value to a level. The type of comparison made will depend on the type of trigger. For example, the trace can be triggered on the rising edge of a signal, on the falling edge, etc. The trigger also allows a delay value to be specified. Trace data will start to be collected N trace periods after the trigger, where N is the delay value. The delay can also be negative, in which case the data will start to be collected before the trigger event. Parameters:

type: The trigger type.

channel: The trace channel to watch. This parameter defaults to 0 if not specified.

level: The trigger level. This parameter defaults to 0 if not specified.

delay: The trigger delay in trace sample periods. Defaults to 0 if not specified.

Continued...

*...Amplifier Trace Methods, continued***Method ReadTraceMaxChannel(maxChannels As Integer)**

Return the maximum number of trace channels supported by the amplifier. Parameters:

maxChannels: The number of channels is returned here.

Method ReadTraceChannel(channel As Integer, traceVar CML_AMP_TRACE_VAR)

Get the amplifier variable current selected on one of the trace channels.

Parameters:

channel: The trace channel to get (zero based).

traceVar: The trace variable assigned to this channel will be returned here.

Method WriteTraceChannel(channel As Integer, traceVar CML_AMP_TRACE_VAR)

Select an amplifier trace variable to be sampled.

Parameters:

channel: The trace channel that the variable will be assigned to (zero based).

traceVar: The trace variable to sample. See [Amplifier Trace Channel Variables \(p. 48\)](#).

Method TraceStart()

Start collecting trace data on the amplifier. The trace will automatically stop once the amplifier's internal trace buffer fills up.

Method TraceStop()

Stop collecting trace data on the amplifier.

Method ReadTraceData(traceDataArray VARIANT, dataCount As Long)

Upload any trace data captured in the amplifier. Trace data should only be uploaded when the traces are stopped.

Uploading data during data collection can cause corrupt data to be uploaded.

The trace data is returned as an array of 32-bit integer values. If there are N currently active trace channels, and M samples of data have been collected, then a total of N x M integer values will be returned. In this case, the samples for channel n ($0 \leq n < N$) will be located at position $n + m*N$ for $0 \leq m < M$.

Parameters:

traceDataArray: An array where the trace data will be returned.

dataCount: On entry to this call, this parameter must hold the maximum number of 32-bit integer values to upload. On successful return this parameter will be filled with the total number of integers uploaded.

B.18.2: Amplifier Trace Trigger Values

The method [WriteTraceTrigger](#) (p. 46) can be used to configure the trace trigger by selecting one of the values below. The method [ReadTraceTrigger](#) (p. 46) can be used to read the current trigger value.

Value (Const)	Description
TRACETRIG_NONE = 0	Trace trigger type none. The trace is triggered immediately on start.
TRACETRIG_ABOVE = 256	Trigger as soon as the value on the selected variable is above the trigger level.
TRACETRIG_BELOW = 512	Trigger as soon as the value on the selected variable is below the trigger level.
TRACETRIG_RISE = 768	Trigger when the value on the selected variable changes from below the trigger level to above it.
TRACETRIG_FALL = 1024	Trigger when the value on the selected variable changes from above the trigger level to below it.
TRACETRIG_BITSET = 1280	Treat the trigger level as a bit mask which selects one or more bits on the selected trace variable. The trigger occurs as soon as any of the selected bits are set.
TRACETRIG_BITCLR = 1536	Treat the trigger level as a bit mask which selects one or more bits on the selected trace variable. The trigger occurs as soon as any of the selected bits are clear.
TRACETRIG_CHANGE = 1792	Trigger any time the selected trace variable value changes.
TRACETRIG_EVENTSET = 2048	Treat the trigger level as a bit mask which selects one or more bits on the amplifier's event status register. The trigger occurs as any of the selected bits are set.
TRACETRIG_EVENTCLR = 2304	Treat the trigger level as a bit mask which selects one or more bits on the amplifier's event status register. The trigger occurs as any of the selected bits are clear.
TRACETRIG_FGEN_CYCLE = 2560	Trigger at the start of the next function generator cycle. This trigger type is only useful when running in function generator mode.
TRACETRIG_NODELAY = 16384	If this bit is set, then the trigger is allowed to occur even if the trace setup delay has not yet occurred.
TRACETRIG_SAMPLE = 32768	Only take a single sample for each trigger. Normally, the occurrence of the trigger causes the trace to begin sampling data and stop when the trace buffer is full.

B.18.3: Amplifier Trace Channel Variables

Following is the list of amplifier variables that can be monitored using the trace feature. A variable can be assigned to a channel using method [WriteTraceChannel](#) (p. 47). A channel's assigned variable can be read using method [ReadTraceChannel](#) (p. 47).

Value (Const)	Description
TRACEVAR_HIGH_VOLT = 6	High voltage bus. Units: 0.1 V.
TRACEVAR_TEMP = 37	Amplifier temperature. Units: degrees C.
TRACEVAR_ANALOG_REF = 5	Analog reference input. Units: mV.
TRACEVAR_ENC_SIN = 46	Analog encoder sine. Units: 0.1 mV.
TRACEVAR_ENC_COS = 47	Analog encoder cosine. Units: 0.1 mV.
TRACEVAR_PHASE = 36	Motor phase angle. Units: 0.1 degree.
TRACEVAR_HALLS = 40	Hall sensor state.
TRACEVAR_INPUTS = 48	Digital input pins (after debounce).
TRACEVAR_RAW_INPUTS = 33	Digital input pins (before debounce).

TRACEVAR_EVENTS = 38	Event status register.
TRACEVAR_EVENTLATCH = 39	Latched version of event status register.
TRACEVAR_CRNT_A = 3	Actual current, current sensor A. Units: 0.01 A.
TRACEVAR_CRNT_B = 4	Actual current, current sensor B. Units: 0.01 A.
TRACEVAR_CRNT_CMD = 7	Commanded current (before limiting). Units: 0.01 A.
TRACEVAR_CRNT_LIM = 8	Commanded current (after limiting). Units: 0.01 A.
TRACEVAR_CRNT_CMD_D = 9	Commanded current, D axis. Units: 0.01 A.
TRACEVAR_CRNT_CMD_Q = 10	Commanded current, Q axis. Units: 0.01 A.
TRACEVAR_CRNT_ACT_D = 13	Actual current, calculated for D axis. Units: 0.01 A.
TRACEVAR_CRNT_ACT_Q = 14	Actual current, calculated for Q axis. Units: 0.01 A.
TRACEVAR_CRNT_ERR_D = 15	Current loop error, D axis. Units: 0.01 A.
TRACEVAR_CRNT_ERR_Q = 16	Current loop error, Q axis. Units: 0.01 A.
TRACEVAR_VOLT_D = 19	Current loop output voltage, D axis. Units: 0.1 V.
TRACEVAR_VOLT_Q = 20	Current loop output voltage, Q axis. Units: 0.1 V.
TRACEVAR_VEL_MTR = 23	Motor velocity filtered. Units: 0.1 encoder counts / second.
TRACEVAR_VEL_RAW = 50	Motor velocity, unfiltered. Units: 0.1 encoder counts / second.
TRACEVAR_VEL_LOAD = 43	Load encoder velocity. Units: 0.1 encoder counts / second.
TRACEVAR_VLOOP_CMD = 24	Velocity loop commanded velocity (before limiting). Units: 0.1 encoder counts / second.
TRACEVAR_VLOOP_LIM = 25	Velocity loop commanded velocity (after limiting). Units: 0.1 encoder counts / second.
TRACEVAR_VLOOP_ERR = 26	Velocity loop error. Units: 0.1 encoder counts / second.
TRACEVAR_LOAD_POS = 28	Load encoder position. Units: encoder counts.
TRACEVAR_MTR_POS = 31	Motor encoder position. Units: encoder counts.
TRACEVAR_POS_ERR = 30	Position error. Units: encoder counts.
TRACEVAR_CMD_POS = 29	Commanded position from trajectory generator. Units: encoder counts.
TRACEVAR_CMD_VEL = 44	Commanded velocity from trajectory generator. Units: 0.1 encoder counts / second.
TRACEVAR_CMD_ACC = 45	Commanded acceleration from trajectory generator. Units: 10 encoder counts / second / second.
TRACEVAR_DEST_POS = 49	Destination position. Units: encoder counts.

B.19: Other Methods and Properties

The following members of *CMLCOMLib.AmpObj* relate to various amplifier functions.

Property CountsPerUnit As Double

Adjustable number of encoder counts/user distance unit. The default value is 1.0 (user distance units are in encoder counts). Also controls velocity, acceleration, and jerk units. These units are always based on a time interval of seconds.

Method Reset()

Resets the Amplifier Object. It resets the amplifier and re-initializes the Amplifier Object.

Property AmpTemp As Integer

Read-only. Get the current amplifier temperature. Units: degrees C.

Property AmpMode As CML_AMP_MODE

Read-only. The currently active amplifier mode of operation. See [Modes of Operation for CML_AMP_MODE](#) (p. 50).

Continued...

*...Other Methods and Properties, continued***Property `AmpModeWrite` As `CML_AMP_MODE`**

Change the amplifier's mode of operation by writing one of the values listed below.

Modes of Operation for `CML_AMP_MODE`

Value (Const)	Description
<code>AMPMODE_SERVO_CAN_PROFILE = 7681</code>	A true CANopen position mode. The CANopen network sends move commands to the amplifier, and the amplifier uses its internal trajectory generator to perform the moves. Conforms to the CANopen Device Profile for Motion Control (DSP-402) profile position mode.
<code>AMPMODE_SERVO_CAN_VELOCITY = 7683</code>	In this mode the CANopen network commands target velocity values to the amplifier. The amplifier uses its programmed acceleration and deceleration values to ramp the velocity up/down to the target. Note that support for profile velocity mode was added in amplifier firmware version 3.06.
<code>AMPMODE_SERVO_CAN_TORQUE = 7684</code>	In this mode the CAN network sends target torque values to the amplifier. When the amplifier is enabled, or the torque command is changed, the motor torque ramps to the new value at the rate programmed in the property TorqueSlope (p. 27). When the amplifier is halted, the torque ramps down at the same rate. When using Profile Torque mode, the property HaltMode (p. 43) can be set to any mode except <code>HALT_DISABLE</code>, because <code>HALT_DISABLE</code> will disable the amplifier with no torque ramp. If the torque target value is changed while the amplifier is enabled, the torque will ramp to the new target. The units for torque target, demand, and actual are per thousand of the motor's rated torque. The units for torque slope are per thousand of the motor's rated torque per second. Profile torque moves are controlled by the object CurrentLoopSettings (p. 27). The profile torque mode cannot be used with a stepper motor.
<code>AMPMODE_SERVO_CAN_HOMING = 7686</code>	A true CANopen position mode. Used to home the motor (find the motor zero position) under CANopen control. Conforms to DSP-402 homing mode.
<code>AMPMODE_SERVO_CAN_PVT = 7687</code>	A true CANopen position mode. In this mode the CANopen master calculates the motor trajectory and streams it over the CANopen network as a set of points that the amplifier interpolates between. This mode conforms to the CANopen device profile for motion control (DSP-402) interpolated position mode.
<code>AMPMODE_STEPPER_CAN_PROFILE = 10241</code>	Same as <code>AMPMODE_SERVO_CAN_PROFILE</code> , but used with stepper capable amplifiers.
<code>AMPMODE_STEPPER_CAN_VELOCITY = 10243</code>	Same as <code>AMPMODE_SERVO_CAN_VELOCITY</code> , but used with stepper capable amplifiers.
<code>AMPMODE_STEPPER_CAN_HOMING = 10246</code>	Same as <code>AMPMODE_SERVO_CAN_HOMING</code> , but used with stepper capable amplifiers.
<code>AMPMODE_STEPPER_CAN_PVT = 10247</code>	Same as <code>AMPMODE_SERVO_CAN_PVT</code> , but used with stepper capable amplifiers.

Continued...

*...Other Methods and Properties, continued***Property HighVoltage As Integer**

Read-only. Gets the high voltage bus voltage. Units: 0.1 V.

Property RefVoltage As Integer

Read-only. Gets the analog reference input voltage. Units: mV.

Method SDO_Dnld(index As Integer, sub As Integer, variantData As VARIANT)

Downloads data to the amplifier via a CAN SDO transfer.

Parameters:

index: Index of a CANopen dictionary object.

sub: Sub-index of a CANopen dictionary object.

variantData: The data that is to be transferred. This data can be one of four types: 8-bit, 16-bit, 32-bit, or String.

Method SDO_Upld(index As Integer, sub As Integer, variantData As VARIANT)

Uploads data from the amplifier via a CAN SDO transfer.

Parameters:

index: Index of a CANopen dictionary object.

sub: Sub-index of a CANopen dictionary object.

variantData: The data that is to be transferred. This data can be one of four types: 8-bit, 16-bit, 32-bit, or String.

APPENDIX

C: THE LINKAGE OBJECT

This appendix describes Copley Motion Objects linkage methods, organized by function.

Note: Unless otherwise stated, all properties described in this appendix have read/write access. All methods return an HRESULT. In the event of an error, CMO reports the error in the form of COM-compatible error objects. See [Error Handling \(p. 15\)](#).

C.1: Linkage Object (LinkageObj)

The Linkage Object allows the programmer to “link” a group of amplifiers to perform coordinated motion. A move using the Linkage Object will start moving all the linked amplifiers at the same time and end the move at the same time.

C.1.1: Linkage Object Methods

All of the methods described in this appendix are members of *CMLCOMLib.LinkageObj*.

Method Initialize(ampArray As Variant)

Parameters:

ampArray: Array of one or more AmpObj (which have already been initialized).

Method MoveTo(positionArray As Variant)
--

Performs a multi-axis move to the positions specified by an array containing one position per axis.

Parameters:

positionArray: Contains the target positions for each axis. Type Double.

Method ReadMoveLimits(vel As Double, acc As Double, dec As Double, jrk As Double)
--

Reads the limits for a multi-axis move.

Parameters:

vel: Move constant velocity. User-defined units/second; see [Units \(p. 15\)](#).

acc: Move acceleration rate. User-defined units/second²; see [Units \(p. 15\)](#).

dec: Move deceleration rate. User-defined units/second²; see [Units \(p. 15\)](#).

jrk: Maximum jerk (maximum rate of change of acceleration). User-defined units/second³; see [Units \(p. 15\)](#).

Method SetMoveLimits(vel As Double, acc As Double, dec As Double, jrk As Double)

Sets the limits for the multi-axis move.

Note: All parameters must be set to a non-zero value.

Parameters:

vel: Move constant velocity. User-defined units/second; see [Units \(p. 15\)](#).

acc: Move acceleration rate. User-defined units/second²; see [Units \(p. 15\)](#).

dec: Move deceleration rate. User-defined units/second²; see [Units \(p. 15\)](#).

jrk: Maximum jerk (maximum rate of change of acceleration). User-defined units/second³; see [Units \(p. 15\)](#).

Continued...

*...Linkage Object Methods, continued***Method TrajectoryInitialize(positions, velocities, times, lowWater As Long)**

Initializes and starts a PVT (Position-Velocity-Time) trajectory move on a Linkage Object (coordinated set of axes). The amplifier will queue up the PVT segments and find the best-fit curve for each set of three PVT segments.

Parameters:

Positions	A two dimensional array declared as numOfSegments, numOfAxis.
Velocities	A two dimensional array declared as numOfSegments, numOfAxis.
Times	A single dimensional array of delta time values representing times from 1 to 255 milliseconds. A time value of zero indicates to the amplifier that the trajectory is complete. The length of this array, as of the position and velocity arrays, must be equal to the number of segments.
lowWater	This is the level of PVT segments left in the Copley Motion Object buffer on the PC at which CMO generates an event requesting more PVT segments. This number must be less than the number of segments.

Method TrajectoryAdd(positions, velocities, times, lowWater As Long)

This method adds PVT segments to the CMO PVT buffer waiting to be sent to the amplifier. (Note: this buffer is used in addition to the 32-deep PVT buffer on the amplifier.) This method is typically used within the handler for the TrajectoryEventNotify event handler such that new PVT segments can be sent to the amplifier when the CMO PVT trajectory generator reaches the lowWater level.

Parameters:

Positions	A two dimensional array declared as numOfSegments, numOfAxis.
Velocities	A two dimensional array declared as numOfSegments, numOfAxis.
Times	A single dimensional array of delta time values representing times from 1 to 255 milliseconds. A time value of zero indicates to the amplifier that the trajectory is complete. The length of this array, as of the position and velocity arrays, must be equal to the number of segments.
lowWater	This is the level of PVT segments left in the Copley Motion Object buffer on the PC at which CMO generates an event requesting more PVT segments. This number must be less than the number of segments.

Method WaitMoveDone(timeout As Long)

Wait until the multi axis move is complete. This method is blocking. When called, it will not return until either the event occurs, or the timeout expires. If a timeout occurs, CMO will report the timeout in the form of a COM-compatible error object. Units: milliseconds.

Method HaltMove()

Halt the current move. The exact type of halt can be programmed individually for each axis using the AmpObj property [HaltMode](#) (p. 43).

Method CreateEvent (mask As CML_LINK_EVENT, condition As CML_EVENT_CONDITION) As EventObj

Creates an instance of the EventObj (see [D: The Event Object](#), p. 57) that monitors amplifier events and sets them up using the specified parameters.

Parameters:

mask:	A bit-mapped value that indicates which events are to be monitored. See C.1.3: CML_LINK_EVENT Values (p. 55).
condition:	The trigger condition for the events that will result in the event callback method being called (e.g. all events in the mask). See Event Conditions (p. 58).
eventObject:	The EventObj instance created by this method.

C.1.3: CML_LINK_EVENT Values

The CreateEvent method can monitor conditions chosen from the list below.

Value	Bit	Description
LINKEVENT_MOVEDONE = 1	0	Set when all amplifiers attached to this linkage have finished their moves and have settled in to position at the end of the move. Cleared when a new move is started on any amplifier.
LINKEVENT_TRJDONE = 2	1	Set when all amplifiers attached to the linkage have finished their moves, but have not yet settled into position at the end of the move. Cleared when a new move is started on any amplifier.
LINKEVENT_NODEGUARD = 4	2	A node guarding (or heartbeat) error has occurred. This indicates that one of the amplifiers failed to respond within the expected amount of time for either a heartbeat or node-guarding message.
LINKEVENT_FAULT = 16	4	A latching fault has occurred on one of the amplifiers attached to this linkage.
LINKEVENT_ERROR = 32	5	A non-latching error has occurred on one of the amplifiers.
LINKEVENT_POSWARN = 64	6	One of the amplifiers is reporting a position-warning event.
LINKEVENT_POSWIN = 128	7	One of the amplifiers is reporting a position window event.
LINKEVENT_VELWIN = 256	8	One of the amplifiers is reporting a velocity window event.
LINKEVENT_DISABLED = 512	9	One of the amplifiers is currently disabled.
LINKEVENT_POSLIM = 1024	10	The positive limit switch of one or more amplifier is currently active.
LINKEVENT_NEGLIM = 2048	11	The negative limit switch of one or more amplifier is currently active.
LINKEVENT_SOFTLIM_POS = 4096	12	The positive software limit of one or more amplifier is currently active.
LINKEVENT_SOFTLIM_NEG = 8192	13	The negative software limit of one or more amplifier is currently active.
LINKEVENT_QUICKSTOP = 16384	14	One of the linkage amplifiers is presently performing a quick stop sequence or is holding in quick stop mode. The amplifier must be disabled to clear this.
LINKEVENT_ABORT= 32768	15	One or more amplifier aborted the last profile without finishing.
LINKEVENT_LOWWATER = 2147483648	31	The active PVT profile is at or below the low water mark and needs more data points.

APPENDIX

D: THE EVENT OBJECT

This appendix describes the use of the Event Object.

Note: All methods return an HRESULT. In the event of an error, CMO reports the error in the form of COM-compatible error objects. See [Error Handling \(p. 15\)](#).

Contents include:

D.1: Event Object	58
D.1.1: Overview	58
D.1.2: Event Object Methods	58
D.1.3: Callback Method	58
D.1.4: Event Conditions	58

D.1: Event Object

D.1.1: Overview

The EventObj allows an application program to be event-driven by having a procedure called when an event occurs in the amplifier. This allows the application program to continue execution while waiting for an event to occur. That is, the program is not blocked. For example, EventObj could call a procedure when a move is done, to perform some action such as performing the next move. The Event Object can be set up to perform a callback on a one-time basis or repeatedly. The EventObj is used in conjunction with the CMO objects that support events: AmpObj, LinkageObj, and IOObj. The CreateEvent method associated with each these three objects sets up the event monitor and returns an instance of the EventObj. See the following descriptions:

CreateEvent Method for:	See:
AmpObj	CreateEvent (p. 45)
LinkageObj	CreateEvent (p. 54)
IOObj	CreateEvent (p. 60)

D.1.2: Event Object Methods

All of the Methods described here are members of *CMLCOMLib.EventObj*.

Method Start (repeats As Boolean, timeout As Long)

Starts the event monitor. Parameters:

repeats: Set to true to set up the event monitor to perform a callback each time the event occurs until the event monitor is stopped. Set to false to set up the event monitor to perform a callback on a one-time basis. When set up for repeating events, the event condition must go away, then come back for the event callback to occur again.

timeout: The timeout for the wait. If <0, then wait indefinitely. Units: milliseconds. If the timeout expires before the event occurs, then the callback routine will be called with its second parameter (hasError) set to true.

Method Stop()

Stops the event monitor.

Method Wait(timeout As Long)

Wait on the event. This method is blocking. When called, it will not return until either the event occurs, or the timeout expires. If a timeout occurs, CMO will report the timeout in the form of a COM compatible error object. Parameters:

timeout: The timeout for the wait. If <0, then wait indefinitely. Units: milliseconds.

D.1.3: Callback Method

EventNotify is a member of *CMLCOMLib.EventObj*.

Event EventNotify(match As CML_AMP_EVENT, timeout As Boolean)

Returns the contents of the register that was set up to trigger the event. The timeout variable will be true if the timeout period expired.

Parameters:

match: The contents of the register that was set up to trigger the event.

timeout: *True* if a timeout or error occurred, *False* otherwise. Should be checked for an error condition before processing the event handling code.

D.1.4: Event Conditions

Each of the following is a member of *CMLCOMLib.CML_EVENT_CONDITION*. Used to select the event triggering condition.

Const CML_EVENT_ANY = 1

Any event occurring.

Const CML_EVENT_ALL = 2

All the events are required.

Const CML_EVENT_NONE = 3

None of the events.

APPENDIX

E: THE I/O OBJECT

This appendix describes IOObj2, used to access I/O devices that comply to the CiA profile DS-401: CANopen Device Profile for Generic I/O Modules.

Note: Unless otherwise stated, all properties described in this appendix have read/write access. All methods return an HRESULT. In the event of an error, CMO reports the error in the form of COM-compatible error objects. See [Error Handling \(p. 15\)](#).

Contents include:

E.1: I/O Modules	60
E.1.1: General IOObj Methods and Properties	60
E.1.2: IOObj Methods and Properties for Analog Inputs	61
E.1.3: IOObj Methods and Properties for Analog Outputs	62
E.1.4: IOObj Methods and Properties for Digital Inputs	63
E.1.5: IOObj Methods and Properties for Digital Outputs	64
E.1.6: IOSettingsObj	64

E.1: I/O Modules

The functions described here support I/O devices that comply to the CiA profile DS-401: CANopen Device Profile for Generic I/O Modules.

E.1.1: General IOObj Methods and Properties

The methods and properties described below are members of *CMLCOMLib.IOObj*.

Method Initialize (canOpenObj As ICANopenObj, nodeId As Integer)

Initializes the I/O device with the CANOpenObj and the specified node ID.

Parameters:

canOpenObj: An instance of a CanOpenObj that has already been initialized.
nodeId: The node ID of the I/O module.

Method InitializeExt (canOpenObj As ICANopenObj, nodeId As Integer, IOSettingsObj As CMLCOMLib.IOSettings)

Initializes the I/O device with the CANOpenObj and the specified node ID. Also, through the IOSettingsObj parameter, allows the CAN network settings for an I/O module to be set at initialization time. This is necessary if PDO mapping is to be turned off for a particular I/O module.

Parameters:

canOpenObj: An instance of a CanOpenObj that has already been initialized.
nodeId: The node ID of the I/O module.
IOSettingsObj: Allows the CAN network settings for an I/O module to be set at initialization time.
See [E.1.6: IOSettingsObj \(p. 64\)](#).

Method CreateEvent (mask As CML_IOMODULE_EVENTS, condition As CML_EVENT_CONDITION, eventObject As EventObj)

Creates an instance of the EventObj (see [The Event Object, p. 57](#)) that monitors I/O events and sets them up using the specified parameters.

Parameters:

mask: A bit-mapped value that indicates which events are to be monitored.
condition: Trigger condition for the events that will result in the callback method being called (e.g. all events in the mask). See [Event Conditions \(p. 58\)](#).
eventObject: The EventObj instance created by this method.

CML_IOMODULE_EVENTS Module Events

Each of the following is a member of *CMLCOMLib.CML_IOModule_Events*. Used to select the IO events trigger state.

Value (Const)	Description
IOEVENT_AIN_PDO0 = 65536	Trigger when any of the first 4 analog inputs generates an event.
IOEVENT_AIN_PDO1 = 131072	Trigger when any of the second 4 analog inputs generates an event.
IOEVENT_AIN_PDO2 = 262144	Trigger when any of the third 4 analog inputs generates an event.
IOEVENT_DIN_PDO0 = 1	Trigger when first 64 digital inputs change state.

Method SDO_Dnld(index As Integer, sub As Integer, variantData As VARIANT)

Downloads data to the IO module via a CAN SDO transfer.

Parameters:

index: Index of a CANopen dictionary object.
sub: Sub-index of a CANopen dictionary object.
variantData: The data that is to be transferred. This data can be one of four types: 8-bit, 16-bit, 32-bit, or String.

Method SDO_Upd(index As Integer, sub As Integer, variantData As VARIANT)

Uploads data from the IO module via a CAN SDO transfer.

Parameters:

index: Index of a CANopen dictionary object.
sub: Sub-index of a CANopen dictionary object.
variantData: The data that is to be transferred. This data can be one of four types: 8-bit, 16-bit, 32-bit, or String.

E.1.2: IOObj Methods and Properties for Analog Inputs

The methods and properties described below, members of *CMLCOMLib.IOObj*, relate to analog inputs.

Method **Ain16Read(channel As Integer, value As Integer, viaSDO As Boolean)**

Reads a 16-bit analog input. Parameters:

channel: The analog input channel ID.
 value: The analog input value read.
 viaSDO: If True, read inputs using SDO transfer. If False (default), use most recently received PDO data, if this input is mapped to a transmit PDO and the PDO is active.

Property **AinIntEnable As Boolean**

Current setting of the global interrupt enable for analog inputs.

Method **AinTrigTypeRead(channel As Integer, trigger As CML_IO_AIN_TRIG_TYPE) / Method AinTrigTypeWrite(channel As Integer, trigger As CML_IO_AIN_TRIG_TYPE)**

Reads/writes the analog input trigger type associated with input channel. Use this command to set/get the type of event associated with an analog input. Parameters:

channel: The analog input channel ID.
 trigger: The analog input trigger type associated with input channel.

Module **Analog Input Trigger Types (CML_IO_AIN_TRIG_TYPE)**

Each of the following is a member of *CMLCOMLib.CML_IO_AIN_Trig_Type*. Each represents an IO trigger type.

Value (Const)	Description
IOAINTRIG_UPPER_LIM = 1	Input above upper limit
IOAINTRIG_LOWER_LIM = 2	Input below lower limit
IOAINTRIG_UDELTA = 4	Input changed by more then the unsigned delta amount
IOAINTRIG_NDELTA = 8	Input reduced by more then the negative delta amount
IOAINTRIG_PDELTA = 16	Input increased by more then the positive delta

Method **Ain16LowerLimitRead (channel As Integer, limit As Integer) /**

Method **Ain16LowerLimitWrite (channel As Integer, limit As Integer)**

Reads/writes the analog input lower limit value as a 16-bit integer. The lower limit defines the value at which an interrupt will be generated if it is enabled. Parameters:

channel: The analog input channel ID.
 limit: The analog input lower limit value

Method **Ain16NegativeDeltaRead(channel As Integer, delta As Integer) /**

Method **Ain16NegativeDeltaWrite(channel As Integer, delta As Integer)**

Reads/writes the analog input negative delta value as a 16-bit integer. The negative delta defines the amount of change at which an interrupt will be generated if it is enabled. Parameters:

channel: The analog input channel ID.
 delta: The analog input negative delta value

Method **Ain16PositiveDeltaRead(channel As Integer, delta As Integer) /**

Method **Ain16PositiveDeltaWrite(channel As Integer, delta As Integer)**

Reads/writes the analog input positive delta value as a 16-bit integer. The positive delta defines the amount of change at which an interrupt will be generated if it is enabled. Parameters:

channel: The analog input channel ID.
 delta: The analog input positive delta value

Continued...

*...IOObj Methods and Properties for Analog Inputs, continued***Method Ain16UnsignedDeltaRead(channel As Integer, delta As Integer) /
Method Ain16UnsignedDeltaWrite(channel As Integer, delta As Integer)**

Reads/writes the analog input unsigned delta value as a 16-bit integer. The unsigned delta defines the amount of change at which an interrupt will be generated if it is enabled. Parameters:

channel: The analog input channel ID.

Delta: The analog input unsigned delta value

**Method Ain16UpperLimitRead(channel As Integer, limit As Integer) /
Method Ain16UpperLimitWrite(channel As Integer, limit As Integer)**

Reads/writes the analog input upper limit value as a 16-bit integer. The upper limit defines the value at which an interrupt will be generated if it is enabled. Parameters:

channel: The analog input channel ID.

Limit: The analog input upper limit value.

E.1.3: IOObj Methods and Properties for Analog Outputs

The methods and properties described below, members of *CMLCOMLib.IOObj*, relate to analog outputs.

Method Aout16Write(channel As Integer, value As Integer, viaSDO As Boolean)

Writes to a 16-bit analog output. Parameters:

channel: The analog input channel ID.

value: The value to write.

viaSDO: If true, the outputs will be written using SDO messages. If false (default), then a PDO will be used if possible.

**Method AoutErrModeRead(channel As Integer, mode As Boolean) /
Method AoutErrModeWrite(channel As Integer, mode As Boolean)**

Reads/writes the analog output error mode. If the error mode is True, then the analog output will change its value to the programmed error value in the case of a device failure. If False, a device failure will not cause a change in the analog output value. Parameters:

channel: The analog output channel ID.

mode: The analog output error mode.

**Method Aout16ErrorValueRead(channel As Integer, error As Integer) /
Method Aout16ErrorValueWrite(channel As Integer, error As Integer)**

Reads/writes the analog out error value. Parameters:

channel: The analog input channel ID.

error: The analog output error value.

E.1.4: IOObj Methods and Properties for Digital Inputs

The methods and properties described below, members of *CMLCOMLib.IOObj*, relate to digital inputs.

Method Din8Read(group As Integer, value As Integer, viaSDO As Boolean)

Reads a group of 8 digital inputs.

Parameters:

group: Identifies which group of 8 to read.

value: The value of the input

viaSDO: If true, read inputs using the SDO transfer. If false (default) use the most recently received PDO data if this input group is mapped to a transmit PDO and the PDO is active .

Property DinIntEnable As Boolean

Current setting of the global interrupt enable of digital inputs.

Method Din8MaskAnyRead(group As Integer, mask As Integer) /
Method Din8MaskAnyWrite(group As Integer, mask As Integer)

Reads/writes the 'any transition' interrupt mask setting for a group of 8 digital inputs. For each input in the group, a value of 1 enables interrupts on any change, and a value of 0 disables the interrupt.

Parameters:

group: Identifies which group of 8 inputs to read/write.

mask: The 'any transition' interrupt mask.

Method Din8MaskHigh2LowRead(group As Integer, mask As Integer) /
Method Din8MaskHigh2LowWrite(group As Integer, mask As Integer)

Reads/writes the 'high to low' interrupt mask setting for a group of 8 digital inputs. For each input in the group, a value of 1 enables interrupts on a high to low transition, and a value of 0 disables the interrupt.

Parameters:

group: Identifies which group of 8 inputs to read/write.

mask: The 'high to low' interrupt mask.

Method Din8MaskLow2HighRead(group As Integer, mask As Integer) /
Method Din8MaskLow2HighWrite(group As Integer, mask As Integer)

Reads/writes the 'low to high' interrupt mask setting for a group of 8 digital inputs. For each input in the group, a value of 1 enables interrupts on a low to high transition, and a value of 0 disables the interrupt.

Parameters:

group: Identifies which group of 8 inputs to read/write.

mask: The 'low to high' interrupt mask.

E.1.5: IOObj Methods and Properties for Digital Outputs

The methods and properties described below, members of *CMLCOMLib.IOObj*, relate to digital outputs.

Method Dout8Write(group As Integer, value As Integer, viaSDO As Boolean)

Writes a group of 8 digital outputs.

Parameters:

group: Identifies which group of outputs to write.

value: Value to write to group

viaSDO: If true, outputs are written using SDO message. If false (default), a PDO is used if possible.

**Method Dout8ErrModeRead(group As Integer, mode As Integer) /
Method Dout8ErrModeWrite(group As Integer, mode As Integer)**

Reads/writes the current error mode setting of a group of 8 digital outputs. For each output in the group, a value of 1 will cause the output to take its programmed error value on a device failure. Setting the mode to 0 will cause the output to hold its programmed value on failure.

Parameters:

group: Identifies the group of outputs to read/write.

mode: The current error mode setting of a group of 8 digital outputs.

**Method Dout8ErrValueRead (group As Integer, error As Integer) /
Method Dout8ErrValueWrite(group As Integer, error As Integer)**

Reads/writes the current error value setting for a group of 8 digital outputs. Error values define the state of the output if a device failure occurs. The error value will only be set for those output pins that have an error mode set to 1. Those with error mode set to zero will not be changed by a device failure.

Parameters:

group: Identifies the group of outputs to read/write.

mode: The current error value setting for a group of 8 digital outputs.

E.1.6: IOSettingsObj

The following IO parameters are members of *CMLCOMLib.IOSettingsObj*. An instance of this object is obtained from the IOObj.

Property useStandardDinPDO

Use the standard digital input PDO object (default = true).

Property UseStandardDoutPDO

Use the standard digital output PDO object (default = true)

Property UseStandardAinPDO

Use the standard analog input PDO object (default = true).

Property UseStandardAoutPDO

Use the standard analog output PDO object (default = true).

heartBeatPeriod

Configures the heartbeat period used by this IO module to transmit its heartbeat message. If this property is set to zero, then the heartbeat protocol is disabled on this module. Units: milliseconds. Default: 0.

heartbeatTimeout

Additional time to wait before generating a heartbeat error. Units: milliseconds. Default: 0.

guardTime

This object gives the time between node-guarding requests that are sent from the network master to this IO module. The IO module will respond to each request with a node-guarding message indicating the internal state of the IO module. Units: milliseconds. Default: 0.

If the IO module has not received a node-guarding request within the time period defined by the product of the guard time and the lifeFactor, the IO module will treat this lack of communication as a fault condition.

lifeFactor

This property gives a multiple of the guardTime parameter. The IO module expects to receive a node-guarding request within the time period defined by the product of the guard time and the lifetime factor. If the IO module has not received a node-guarding request within this time period, it treats this condition as a fault. Default = 3.

APPENDIX

F: CopleyMotionLibrary OBJECT

This appendix describes CopleyMotionLibraryObj, which includes the ability to log communication traffic for debugging purposes.

Contents include:

F.1: CopleyMotionLibraryObj	66
F.1.1: CopleyMotionLibraryObj	66

F.1: CopleyMotionLibraryObj

F.1.1: CopleyMotionLibraryObj

All the methods and properties described below are members of *CMLCOMLib.CopleyMotionLibraryObj*.

Property VersionString As String

The version number of the Copley Motion Libraries used by CMO.

Property DebugLevel As Long

Debug message level. Setting this property greater than zero results in debug messages being written to a log file as specified by the LogFileName property below. If the level was previously set higher than 0, and is then set to 0, any open log file will be closed. The default log level is 0 (no messages).

Property MaxLogSize As Long

Maximum Copley Motion Libraries log file size. Once the log file exceeds MaxLogSize, it is renamed logfilename.bak (where logfilename is replaced by the log file name), and a new log file is started. Old backup log files are overwritten. The default maximum log size is 1,000,000 bytes.

Property LogFileName As String

Name of the Copley Motion Libraries debug message log file. This file is used to log debug messages. The file will be created (or truncated if it already exists) when the first message is written to the file. Note that the debug level must be set > 0 for any messages to be written.

Note: For C and C++ users, two special file names are also supported. "stdout" causes the messages to be written to the C standard output stream, and "stderr" causes them to be written to C standard error stream. The default log file name is "cml.log"

APPENDIX

G: MASKING

G.1: Masking

G.1.1: Selecting Bits in a Register

A register mask describes a selection of bits in a register. Copley Motion Objects uses masks to:

- 1 Configure methods to monitor the states of selected register bits.
- 2 Directly read or write the states of register bits.

A register mask describes a set of bits. The mask is typically represented by a binary number. For convenience, the register descriptions in this manual provide the decimal mask values for each bit. The decimal equivalent can be calculated as 2^n , where n = the bit number

For instance, here is a partial description of the amplifier's event status register:

Bit	Definition	Decimal Equivalent of Mask Value
0	Amplifier short circuit.	1 ($=2^0$)
1	Amplifier over temperature.	2 ($=2^1$)
2	Amplifier over voltage.	4 ($=2^2$)
3	Amplifier under voltage.	8 ($=2^3$)

For a full description, see [B.11.2: Amplifier Event Status Register Values](#) (p. 32).

A mask is defined by setting (to value 1) the mask bits that correspond to selected register bits. A simple way to do this is add the decimal equivalents of the mask values of the selected bits. Here are three sample masks for the event status register:

	Register Bits				
Bit Number	3	2	1	0	Note: Add the decimal equivalents of the selected bits to determine the mask's decimal value.
Definition	Under Voltage	Over Voltage	Over Temperature	Short Circuit	
Decimal Equivalent	8	4	2	1	
Example Masks	Mask Bits				Decimal Equivalent
Short Circuit Only	0	0	0	1	1
Over Temperature Only	0	0	1	0	2
Over Voltage Only	0	1	0	0	4
Under Voltage Only	1	0	0	0	8
Under or Over Voltage	1	1	0	0	12 (=8+4)

Continue to [G.1.2: Mask Usage Examples](#) (p. 68).

G.1.2: Mask Usage Examples

For instance, the method [WriteOutputConfigExt](#) (p. 37) can configure an output to track one or more bits in the amplifier's event status word.

Example 1: Configure OUT1 to Track Short Circuit Conditions

The general format of [WriteOutputConfigExt](#) is:

```
WriteOutputConfigExt(pin As Integer, config As
    CML_OUTPUT_PIN_CONFIG, param1 As Integer, Param2 As
    Integer)
```

To configure OUT1 to track short circuit conditions, call the method as follows:

```
WriteOutputConfig 0, OUTPUT_CONFIGURATION_EVENT_STATUS_HIGH,
1, 0
```

The parameter values are described below.

Parameter	Value	Meaning
pin	0	Assign the configuration to OUT1.
config	OUTPUT_CONFIGURATION_EVENT_STATUS_HIGH	The output pin follows the mask of the amplifier's event status register and is active high.
param1	1	Track register Bit 0, Amplifier short circuit.
param2	0	This parameter is ignored for this configuration.

Example 2: Configure OUT4 to Track Over Temperature and Over Voltage Conditions

In this example, the mask is a sum of two values:

```
WriteOutputConfigExt 3, OUTPUT_CONFIGURATION_EVENT_STATUS_HIGH, 12, 0
```

The parameter values are described below.

Parameter	Value	Meaning
pin	3	Assign the configuration to OUT4.
config	OUTPUT_CONFIGURATION_EVENT_STATUS_HIGH	The output pin follows the mask of the amplifier's event status register and is active high.
param1	12	Track register bits 3, Amplifier under voltage, and 2, Amplifier over voltage. Note that the selection is a bitwise "Or." OUT4 will go active if an under or over voltage condition occurs.
param2	0	This parameter is ignored for this configuration.

APPENDIX

H: OBJECT REVISION HISTORY

H.1: Object Revision History

All legacy objects continue to function in subsequent releases of the software. All new versions of objects provide the functions of previous versions, plus the additions noted.

Object Description	Object Revisions	Changes
Amplifier Object	AmpObj6	Updates.
	AmpObj5	
	AmpObj4	Added WriteOutputConfigExt method. Supercedes WriteOutputConfig. Added ReadOutputConfigExt method. Supercedes ReadOutputConfig. Expanded list of output pin configuration values to include position triggered and trajectory status functions.
	AmpObj3	Added methods and properties to support trace functionality.
	AmpObj2	Added AmpModeWrite property to allow changing of amplifier mode. Added a new mode to support profile torque mode operation. Added four new properties to support profile torque mode operation.
	AmpObj	Original.
Position Loop Settings Object	PositionLoopSettings2	Added PosLoopScale property.
	PositionLoopSettings	Original.
Motor Info Object	MotorInfoObj2	Added properties: resolverCycles and hallvelocityShift.
	MotorInfoObj	Original.
I/O Object	IOObj2	Added InitializeExt method.
	IOObj	Original.

Copley Motion Objects (CMO) Programmer's Guide

P/N 95-00290-000

Revision 4

June 2008

© 2004-2008

Copley Controls Corporation

20 Dan Road

Canton, MA 02021 USA

All rights reserved